


<u>SHEE I</u>	INDEX
1	COVER PAGE
2	DRAINAGE PLAN
3	GRADING PLAN
4	WATER AND SEWE
5	TESC PLAN
6	DRAINAGE DETAILS
7	DRAINAGE, SEWER



K

0

C

AM

S

NYAH 7466 AERCER

Z

S

5

Õ

TSIDE MALL ST. SUIT WASHINGTON

S

**LA** 1320 N

Σ

6

S

Ń

M

UR

S

S

C Ш Ш Ž

NG 

**GE** 

PA

(PER STATUTORY WARRANTY DEED RECORDING# 20150526001877)

THAT PORTION OF LOT 20,, BLOCK 3, FLOOD'S LAKE SIDE TRACTS, ACCORDING TO THE PLAT THEREOF RECORDED IN VOLUME 20 OF PLATS, PAGE 83, RECORDS OF KING COUNTY, WASHINGTON, LYING WEST OF A LINE DESCRIBED AS FOLLOWS:

BEGINNING AT THE MONUMENT MARKING THE INTERSECTION OF THE ORIGINAL PLATTED CENTER LINE OF EAST MERCER WAY WITH THE WESTERLY EXTENSION OF THE SOUTH LINE OF SAID LOT 20; THENCE NORTH. 89"56'32" EAST ALONG SAID WESTERLY EXTENSION AND ALONG SAID SOUTH LINE 169.30 FEET TO THE TRUE POINT OF BEGINNING OF THE LINE HEREIN DESCRIBED; THENCE NORTH 0°03'28" WEST TO THE NORTH LINE OF SAID LOT 20 AND THE

TOGETHER WITH THAT PORTION OF VACATED EAST MERCER WAY ADJOINING THE ABOVE DESCRIBED PROPERTY ON THE WEST;

## PARCEL B:

AN EASEMENT FOR INGRESS AND EGRESS TO LAKE WASHINGTON OVER THE NORTH 5.0 FEET OF THAT PORTION OF SAID TRACT 20 LYINE EASTERLY OF THE EAST LINE OF THE ABOVE DESCRIBED TRACT;

SITUATE IN THE COUNTY OF KING, STATE OF WASHINGTON.

END OF THE LINE HEREIN DESCRIBED;

# **SURVEYOR'S NOTES**

- 1. THE TOPOGRAPHIC SURVEY SHOWN HEREON WAS PERFORMED IN MARCH OF 2018. THE FIELD DATA WAS COLLECTED AND RECORDED ON MAGNETIC MEDIA THROUGH AN ELECTRONIC THEODOLITE. THE DATA FILE IS ARCHIVED ON DISC OR CD. WRITTEN FIELD NOTES MAY NOT EXIST. CONTOURS ARE SHOWN FOR CONVENIENCE ONLY. DESIGN SHOULD RELY ON SPOT ELEVATIONS.
- 2. ALL MONUMENTS SHOWN HEREON WERE LOCATED DURING THE COURSE OF THIS SURVEY UNLESS OTHERWISE NOTED.
- 3. BURIED UTILITIES SHOWN BASED ON RECORDS FURNISHED BY OTHERS AND VERIFIED WHERE POSSIBLE IN THE FIELD. TERRANE ASSUMES NO LIABILITY FOR THE ACCURACY OF THOSE RECORDS OR ACCEPT RESPONSIBILITY FOR UNDERGROUND LINES WHICH ARE NOT MADE PUBLIC RECORD. FOR THE FINAL LOCATION OF EXISTING UTILITIES IN AREAS CRITICAL TO DESIGN CONTACT THE UTILITY OWNER/AGENCY. AS ALWAYS, CALL 1-800-424-5555 BEFORE CONSTRUCTION.
- 4. SUBJECT PROPERTY TAX PARCEL NO. 257950-0136
- 5. SUBJECT PROPERTY AREA PER THIS SURVEY IS 10,150 ±S.F. (0.23 ACRES)
- 6. THIS SURVEY WAS PERFORMED WITHOUT THE BENEFIT OF A TITLE REPORT. EASEMENTS AND OTHER ENCUMBRANCES MAY EXIST THAT ARE NOT SHOWN HEREON.
- 7. FIELD DATA FOR THIS SURVEY WAS OBTAINED BY DIRECT FIELD MEASUREMENTS WITH A CALIBRATED ELECTRONIC 5-SECOND TOTAL STATION AND/OR SURVEY GRADE GPS OBSERVATIONS. ALL ANGULAR AND LINEAR RELATIONSHIPS ARE ACCURATE AND MEET THE STANDARDS SET BY WAC 332-130-090.

## **SEWER NOTE:**

EXISTING SEWER LINE TO BE INSPECTED ONCE EXPOSED. IF SEWER NEEDS TO BE REPLACED PER INSPECTORS RECOMMENDATION IT SHALL BE REPLACED WITH 6-INCH PVC.

# **PROJECT CONTACTS**


OWNER: RAMAIYAH & SUBRAMANIAN BAYLIS ARCHITECTS 7466 E MERCER WAY 10801 MAIN ST, MERCER ISLAND, WA 98040 BELLEVUE, WA 98

APPLICANT/ARCHITECT: BRANDB@BAYLISA 425-679-5202

3/7/


CIVIL ENGINEER:

TS TS ¥110 3004 RCHITECTS.COM	EASTSIDE COI 1320 NW MAI ISSAQUAH, W PHONE: 425 CONTACT: RC	NSULTANTS, I LL STREET, S A 98027 5.392.5351	TE B	
REDEEPIN		EX LOCATIO 0 T. 24 N.R.		JOB NO. 24014
ASHIN CALL				DATE 3/24
22				SCALE 1"=10'
				DESIGNED R.S.F.
53 0 2		<i>└</i>	,	DRAWN J.W.T.
ENGINE				CHECKED R.S.F.
ENCINE				APPROVED R.S.F.
2024				SHEET <u>1</u> OF <u>14</u>



TOTAL	SITE	AREA	10,150SF	– RIGHT	OF	WAY	AREA	280S
NET L	OT A	REA: 1	0.150–280	)=9.870 S	SF			

HARDSCAPE	
AUTOCOURT & STAIRS	818 S.F
WALKWAY	60 S.F
LANDSCAPED STAIR	8 S.F
HARDSCAPE TOTAL:	886 S.F
9,870 SF X 9% = 888.3 SF 886 SF < 8	88.3 SFOK
LOT COVERAGE	
HARDSCAPE TOTAL	886 S.F
UNDER STRUCTURE	2,546 S.F
TOTAL LOT COVERAGE:	3,432 S.F
9,870SF X 35%=3454.5 SF 3,432SF < 3,4	54.5SFOK
LANDSCAPING	
LANDSCAPING	6,107 S.F
PLANTER	55 S.F
RAMPED BARK PATH	317 S.F
STEPPED EGRESS WELL	114 S.F
TOTAL LANDSCAPING:	6,591 S.F
9,870SF X 65%=6,415.5 SF 6,591 SF < 6,41	15.5 SFOK



G

4

Z

4

A M V A V

SU

NYAH 7466 AERCER

Z

Z

5

O

TSIDE MALL ST. SUIT WASHINGTON

2

6

S

**X** 

**M** 

C

S

S

Ш Ш N

NG L

Ζ

РГ

(PER STATUTORY WARRANTY DEED RECORDING# 20150526001877)

THAT PORTION OF LOT 20,, BLOCK 3, FLOOD'S LAKE SIDE TRACTS, ACCORDING TO THE PLAT THEREOF RECORDED IN VOLUME 20 OF PLATS, PAGE 83, RECORDS OF KING COUNTY, WASHINGTON, LYING WEST OF A LINE DESCRIBED AS FOLLOWS:

BEGINNING AT THE MONUMENT MARKING THE INTERSECTION OF THE ORIGINAL PLATTED CENTER LINE OF EAST MERCER WAY WITH THE WESTERLY EXTENSION OF THE SOUTH LINE OF SAID LOT 20; THENCE NORTH. 89"56'32" EAST ALONG SAID WESTERLY EXTENSION AND ALONG SAID SOUTH LINE 169.30 FEET TO THE TRUE POINT OF BEGINNING OF THE LINE HEREIN DESCRIBED; THENCE NORTH 0°03'28" WEST TO THE NORTH LINE OF SAID LOT 20 AND THE END OF THE LINE HEREIN DESCRIBED;

TOGETHER WITH THAT PORTION OF VACATED EAST MERCER WAY ADJOINING THE ABOVE DESCRIBED PROPERTY ON THE WEST;

PARCEL B: AN EASEMENT FOR INGRESS AND EGRESS TO LAKE WASHINGTON OVER THE NORTH 5.0 FEET OF THAT PORTION OF SAID TRACT 20 LYINE EASTERLY OF THE EAST LINE OF THE ABOVE DESCRIBED TRACT;

SITUATE IN THE COUNTY OF KING, STATE OF WASHINGTON.

# **SURVEYOR'S NOTES**

- 1. THE TOPOGRAPHIC SURVEY SHOWN HEREON WAS PERFORMED IN MARCH OF 2018. THE FIELD DATA WAS COLLECTED AND RECORDED ON MAGNETIC MEDIA THROUGH AN ELECTRONIC THEODOLITE. THE DATA FILE IS ARCHIVED ON DISC OR CD. WRITTEN FIELD NOTES MAY NOT EXIST. CONTOURS ARE SHOWN FOR CONVENIENCE ONLY. DESIGN SHOULD RELY ON SPOT ELEVATIONS.
- 2. ALL MONUMENTS SHOWN HEREON WERE LOCATED DURING THE COURSE OF THIS SURVEY UNLESS OTHERWISE NOTED.
- 3. BURIED UTILITIES SHOWN BASED ON RECORDS FURNISHED BY OTHERS AND VERIFIED WHERE POSSIBLE IN THE FIELD. TERRANE ASSUMES NO LIABILITY FOR THE ACCURACY OF THOSE RECORDS OR ACCEPT RESPONSIBILITY FOR UNDERGROUND LINES WHICH ARE NOT MADE PUBLIC RECORD. FOR THE FINAL LOCATION OF EXISTING UTILITIES IN AREAS CRITICAL TO DESIGN CONTACT THE UTILITY OWNER/AGENCY. AS ALWAYS, CALL 1-800-424-5555 BEFORE CONSTRUCTION.
- 4. SUBJECT PROPERTY TAX PARCEL NO. 257950-0136
- 5. SUBJECT PROPERTY AREA PER THIS SURVEY IS 10,150 ±S.F. (0.23 ACRES)
- 6. THIS SURVEY WAS PERFORMED WITHOUT THE BENEFIT OF A TITLE REPORT. EASEMENTS AND OTHER ENCUMBRANCES MAY EXIST THAT ARE NOT SHOWN HEREON.
- 7. FIELD DATA FOR THIS SURVEY WAS OBTAINED BY DIRECT FIELD MEASUREMENTS WITH A CALIBRATED ELECTRONIC 5-SECOND TOTAL STATION AND/OR SURVEY GRADE GPS OBSERVATIONS. ALL ANGULAR AND LINEAR RELATIONSHIPS ARE ACCURATE AND MEET THE STANDARDS SET BY WAC 332-130-090.

# **SEWER NOTE:**

EXISTING SEWER LINE TO BE INSPECTED ONCE EXPOSED. IF SEWER NEEDS TO BE REPLACED PER INSPECTORS RECOMMENDATION IT SHALL BE REPLACED WITH 6-INCH PVC.


# **PROJECT CONTACTS**


OWNER: RAMAIYAH & SUBRAMANIAN BAYLIS ARCHITECTS 7466 E MERCER WAY 10801 MAIN ST, #110 MERCER ISLAND, WA 98040 BELLEVUE, WA 98004


APPLICANT/ARCHITECT: BRANDBOBAYLISARCHITECTS.COM 425-679-5202

3/7/2024

						<b>EAS</b> <sup>+</sup> 1320 N.W. 1 1520 N.W. 1 1520 N.W. 1
М	EASTS 1320 ISSAQ PHON	ENGINEE SIDE CON NW MAL UAH, W/ E: 425 ACT: RO	SULTAN L STREE 98027 .392.53	T, STE		
			EX LOC 0 T. 24.			
	/					JOB NO. 24014
						DATE 3/24
						SCALE 1"=10' DESIGNED R.S.F.
						DESIGNED R.S.F. DRAWN J.W.T.
			<u> </u>	$\mathcal{O}_{\mathbb{Z}}$		CHECKED R.S.F.
				///		APPROVED R.S.F.
				///	1	SHEET 2_OF_14_







DING

4

G

ร

IYAH 7466 MERCER

Z

Z

4

5

O

TSIDE MALL ST. SUIT

Σ

6

S

Ń

Ν

5

S

S

C Ш Ш Z

NG 

Ζ

J

РГ

(PER STATUTORY WARRANTY DEED RECORDING# 20150526001877)

THAT PORTION OF LOT 20,, BLOCK 3, FLOOD'S LAKE SIDE TRACTS, ACCORDING TO THE PLAT THEREOF RECORDED IN VOLUME 20 OF PLATS, PAGE 83, RECORDS OF KING COUNTY, WASHINGTON, LYING WEST OF A LINE DESCRIBED AS FOLLOWS:

BEGINNING AT THE MONUMENT MARKING THE INTERSECTION OF THE ORIGINAL PLATTED CENTER LINE OF EAST MERCER WAY WITH THE WESTERLY EXTENSION OF THE SOUTH LINE OF SAID LOT 20; THENCE NORTH. 89"56'32" EAST ALONG SAID WESTERLY EXTENSION AND ALONG SAID SOUTH LINE 169.30 FEET TO THE TRUE POINT OF BEGINNING OF THE LINE HEREIN DESCRIBED; THENCE NORTH 0°03'28" WEST TO THE NORTH LINE OF SAID LOT 20 AND THE

TOGETHER WITH THAT PORTION OF VACATED EAST MERCER WAY ADJOINING THE ABOVE DESCRIBED PROPERTY ON THE WEST;

## PARCEL B:

AN EASEMENT FOR INGRESS AND EGRESS TO LAKE WASHINGTON OVER THE NORTH 5.0 FEET OF THAT PORTION OF SAID TRACT 20 LYINE EASTERLY OF THE EAST LINE OF THE ABOVE DESCRIBED TRACT;

SITUATE IN THE COUNTY OF KING, STATE OF WASHINGTON.

END OF THE LINE HEREIN DESCRIBED;

# **SURVEYOR'S NOTES**

- 1. THE TOPOGRAPHIC SURVEY SHOWN HEREON WAS PERFORMED IN MARCH OF 2018. THE FIELD DATA WAS COLLECTED AND RECORDED ON MAGNETIC MEDIA THROUGH AN ELECTRONIC THEODOLITE. THE DATA FILE IS ARCHIVED ON DISC OR CD. WRITTEN FIELD NOTES MAY NOT EXIST. CONTOURS ARE SHOWN FOR CONVENIENCE ONLY. DESIGN SHOULD RELY ON SPOT ELEVATIONS.
- 2. ALL MONUMENTS SHOWN HEREON WERE LOCATED DURING THE COURSE OF THIS SURVEY UNLESS OTHERWISE NOTED.
- 3. BURIED UTILITIES SHOWN BASED ON RECORDS FURNISHED BY OTHERS AND VERIFIED WHERE POSSIBLE IN THE FIELD. TERRANE ASSUMES NO LIABILITY FOR THE ACCURACY OF THOSE RECORDS OR ACCEPT RESPONSIBILITY FOR UNDERGROUND LINES WHICH ARE NOT MADE PUBLIC RECORD. FOR THE FINAL LOCATION OF EXISTING UTILITIES IN AREAS CRITICAL TO DESIGN CONTACT THE UTILITY OWNER/AGENCY. AS ALWAYS, CALL 1-800-424-5555 BEFORE CONSTRUCTION.
- 4. SUBJECT PROPERTY TAX PARCEL NO. 257950-0136
- 5. SUBJECT PROPERTY AREA PER THIS SURVEY IS 10,150 ±S.F. (0.23 ACRES)
- 6. THIS SURVEY WAS PERFORMED WITHOUT THE BENEFIT OF A TITLE REPORT. EASEMENTS AND OTHER ENCUMBRANCES MAY EXIST THAT ARE NOT SHOWN HEREON.
- 7. FIELD DATA FOR THIS SURVEY WAS OBTAINED BY DIRECT FIELD MEASUREMENTS WITH A CALIBRATED ELECTRONIC 5-SECOND TOTAL STATION AND/OR SURVEY GRADE GPS OBSERVATIONS. ALL ANGULAR AND LINEAR RELATIONSHIPS ARE ACCURATE AND MEET THE STANDARDS SET BY WAC 332-130-090.

## **SEWER NOTE:**

EXISTING SEWER LINE TO BE INSPECTED ONCE EXPOSED. IF SEWER NEEDS TO BE REPLACED PER INSPECTORS RECOMMENDATION IT SHALL BE REPLACED WITH 6-INCH PVC.

# **PROJECT CONTACTS**


OWNER: RAMAIYAH & SUBRAMANIAN BAYLIS ARCHITECTS 7466 E MERCER WAY 10801 MAIN ST, #110 MERCER ISLAND, WA 98040 BELLEVUE, WA 98004


APPLICANT/ARCHITECT: BRANDB@BAYLISARCHITECTS.COM PHONE: 425.392.5351 425-679-5202


CIVIL ENGINEER: EASTSIDE CONSULTANTS, INC 1320 NW MALL STREET, STE B ISSAQUAH, WA 98027 CONTACT: RONALD FREDERIKSEN

			CATION.	
	SEC. 3	0 T.24.	N.R. 51	ī
OF WASKING				
Contraction of the second seco				
3/7/2024				

	7. W.M.	N.R. 54	0 T.24.	SEC. 3
JOB NO. 24014				
DATE 3/24				
SCALE 1"=10'				
DESIGNED R.S.F.				
DRAWN J.W.T.			(.?	
CHECKED R.S.F.		)//		
APPROVED R.S.F.		//		
SHEET 3 OF 14				







AN

Ц

2

ME

SE

QN

Ш F

MA

AM

SU

NYAH 7466 AERCER

Z

Z

4

5

O

TSIDE MALL ST., SUIT WASHINGTON

Σ

6

S

Ń

ZE

S

S

0 Ш Ш Ž

5 Ζ 11

# LEGAL DESCRIPTION

(PER STATUTORY WARRANTY DEED RECORDING# 20150526001877)

THAT PORTION OF LOT 20,, BLOCK 3, FLOOD'S LAKE SIDE TRACTS, ACCORDING TO THE PLAT THEREOF RECORDED IN VOLUME 20 OF PLATS, PAGE 83, RECORDS OF KING COUNTY, WASHINGTON, LYING WEST OF A LINE DESCRIBED AS FOLLOWS:

BEGINNING AT THE MONUMENT MARKING THE INTERSECTION OF THE ORIGINAL PLATTED CENTER LINE OF EAST MERCER WAY WITH THE WESTERLY EXTENSION OF THE SOUTH LINE OF SAID LOT 20; THENCE NORTH. 89"56'32" EAST ALONG SAID WESTERLY EXTENSION AND ALONG SAID SOUTH LINE 169.30 FEET TO THE TRUE POINT OF BEGINNING OF THE LINE HEREIN DESCRIBED;

THENCE NORTH 0°03'28" WEST TO THE NORTH LINE OF SAID LOT 20 AND THE END OF THE LINE HEREIN DESCRIBED;

TOGETHER WITH THAT PORTION OF VACATED EAST MERCER WAY ADJOINING THE ABOVE DESCRIBED PROPERTY ON THE WEST;

PARCEL B:

AN EASEMENT FOR INGRESS AND EGRESS TO LAKE WASHINGTON OVER THE NORTH 5.0 FEET OF THAT PORTION OF SAID TRACT 20 LYINE EASTERLY OF THE EAST LINE OF THE ABOVE DESCRIBED TRACT;

SITUATE IN THE COUNTY OF KING, STATE OF WASHINGTON.

# **SURVEYOR'S NOTES**

- 1. THE TOPOGRAPHIC SURVEY SHOWN HEREON WAS PERFORMED IN MARCH OF 2018. THE FIELD DATA WAS COLLECTED AND RECORDED ON MAGNETIC MEDIA THROUGH AN ELECTRONIC THEODOLITE. THE DATA FILE IS ARCHIVED ON DISC OR CD. WRITTEN FIELD NOTES MAY NOT EXIST. CONTOURS ARE SHOWN FOR CONVENIENCE ONLY. DESIGN SHOULD RELY ON SPOT ELEVATIONS.
- 2. ALL MONUMENTS SHOWN HEREON WERE LOCATED DURING THE COURSE OF THIS SURVEY UNLESS OTHERWISE NOTED.
- 3. BURIED UTILITIES SHOWN BASED ON RECORDS FURNISHED BY OTHERS AND VERIFIED WHERE POSSIBLE IN THE FIELD. TERRANE ASSUMES NO LIABILITY FOR THE ACCURACY OF THOSE RECORDS OR ACCEPT RESPONSIBILITY FOR UNDERGROUND LINES WHICH ARE NOT MADE PUBLIC RECORD. FOR THE FINAL LOCATION OF EXISTING UTILITIES IN AREAS CRITICAL TO DESIGN CONTACT THE UTILITY OWNER/AGENCY. AS ALWAYS, CALL 1-800-424-5555 BEFORE CONSTRUCTION.
- 4. SUBJECT PROPERTY TAX PARCEL NO. 257950-0136
- 5. SUBJECT PROPERTY AREA PER THIS SURVEY IS 10,150 ±S.F. (0.23 ACRES)
- 6. THIS SURVEY WAS PERFORMED WITHOUT THE BENEFIT OF A TITLE REPORT. EASEMENTS AND OTHER ENCUMBRANCES MAY EXIST THAT ARE NOT SHOWN HEREON.
- 7. FIELD DATA FOR THIS SURVEY WAS OBTAINED BY DIRECT FIELD MEASUREMENTS WITH A CALIBRATED ELECTRONIC 5-SECOND TOTAL STATION AND/OR SURVEY GRADE GPS OBSERVATIONS. ALL ANGULAR AND LINEAR RELATIONSHIPS ARE ACCURATE AND MEET THE STANDARDS SET BY WAC 332-130-090.

## **SEWER NOTE:**

EXISTING SEWER LINE TO BE INSPECTED ONCE EXPOSED. IF SEWER NEEDS TO BE REPLACED PER INSPECTORS RECOMMENDATION IT SHALL BE REPLACED WITH 6-INCH PVC.

# **PROJECT CONTACTS**

OWNER: RAMAIYAH & SUBRAMANIAN BAYLIS ARCHITECTS 7466 E MERCER WAY 10801 MAIN ST, #110 MERCER ISLAND, WA 98040 BELLEVUE, WA 98004


APPLICANT/ARCHITECT: BRANDB@BAYLISARCHITECTS.COM PHONE: 425.392.5351 425-679-5202

CIVIL ENGINEER: EASTSIDE CONSULTANTS, INC 1320 NW MALL STREET, STE B ISSAQUAH, WA 98027 CONTACT: RONALD FREDERIKSEN


		CATION: N.R. 51	
S FREDE WASHING			
2 65 2 2 E	0		
SOVAL EVEN			
3/7/2024			


I.R. **5E.** W.M. JOB NO. 24014 DATE 3/24 SCALE 1"=10' DESIGNED R.S.F. DRAWN J.W.T. CHECKED R.S.F. APPROVED R.S.F.

SHEET 4 OF 14



# RAMAIYAH AND SUBRAMANIAN RESIDENCE NW 1/4, SE 1/4, SECTION 30, TOWNSHIP 24 NORTH, RANGE 5 EAST, W.M. MERCER ISLAND, WASHINGTON - APPRØX LOC OF GAS PER CITY RECORDS SILT FENCE ON ALL DOWN GRADIENT SLOPES LOT 19 \_3⁄2 2.62 2.4 SET PK NAIL 人人人人人人 (WASHER) N 89°49'56" E 126.78' BLOCK ° √14> (2) HIGH VISIBILITY PLASTIC OR METAL FENCE PER BMP C103 \_\_\_\_\_ $\langle 3 \rangle$ SILT FENCE PER BMP C233 STABILIZED CONSTRUCTION ENTRANCE/EXIT PER BMP C105 (5) WATTLES PER BMP C235 ROCKERY 2.0'E (13)(15)(16) <mark>┎┲╼╼╼╼┹</mark>┛ ┶<u>╞╼╼╼╼╼╼</u>╤<u>╤</u>╞╼═╼═<u>╼╼</u>╞<u>╼╼╼╆</u>╶╴╞ ROCKERY 2.0'E 1000 REBAR/CAP -169.30 \_\_\_\_ YYYYYY Re Co CLEARING LIMITS FOUND 1.1" IRON PIPE -(ABOVE GROUND) 1.98'W X 0.73'S FROM PROP. COR. SILT FENCE ON ALL DOWN GRADIENT SLOPES





SITUATE IN THE COUNTY OF KING, STATE OF WASHINGTON.

# **SURVEYOR'S NOTES**

- 1. THE TOPOGRAPHIC SURVEY SHOWN HEREON WAS PERFORMED IN MARCH OF 2018. THE FIELD DATA WAS COLLECTED AND RECORDED ON MAGNETIC MEDIA THROUGH AN ELECTRONIC THEODOLITE. THE DATA FILE IS ARCHIVED ON DISC OR CD. WRITTEN FIELD NOTES MAY NOT EXIST. CONTOURS ARE SHOWN FOR CONVENIENCE ONLY. DESIGN SHOULD RELY ON SPOT ELEVATIONS.
- 2. ALL MONUMENTS SHOWN HEREON WERE LOCATED DURING THE COURSE OF THIS SURVEY UNLESS OTHERWISE NOTED.
- BURIED UTILITIES SHOWN BASED ON RECORDS FURNISHED BY OTHERS D VERIFIED WHERE POSSIBLE IN THE FIELD. TERRANE ASSUMES NO LIABILITY FOR THE ACCURACY OF THOSE RECORDS OR ACCEPT RESPONSIBILITY FOR UNDERGROUND LINES WHICH ARE NOT MADE PUBLIC RECORD. FOR THE FINAL LOCATION OF EXISTING UTILITIES IN AREAS CRITICAL TO DESIGN CONTACT THE UTILITY OWNER/AGENCY. AS ALWAYS, CALL 1-800-424-5555 BEFORE CONSTRUCTION.
- 4. SUBJECT PROPERTY TAX PARCEL NO. 257950-0136
- 5. SUBJECT PROPERTY AREA PER THIS SURVEY IS 10,150 ±S.F. (0.23 ACRES)
- 6. THIS SURVEY WAS PERFORMED WITHOUT THE BENEFIT OF A TITLE REPORT. EASEMENTS AND OTHER ENCUMBRANCES MAY EXIST THAT ARE NOT SHOWN HEREON.
- 7. FIELD DATA FOR THIS SURVEY WAS OBTAINED BY DIRECT FIELD MEASUREMENTS WITH A CALIBRATED ELECTRONIC 5-SECOND TOTAL STATION AND/OR SURVEY GRADE GPS OBSERVATIONS. ALL ANGULAR AND LINEAR RELATIONSHIPS ARE ACCURATE AND MEET THE STANDARDS SET BY WAC 332-130-090.

## **SEWER NOTE:**

EXISTING SEWER LINE TO BE INSPECTED ONCE EXPOSED. IF SEWER NEEDS TO BE REPLACED PER INSPECTORS RECOMMENDATION IT SHALL BE REPLACED WITH 6-INCH PVC.

# **PROJECT CONTACTS**

OWNER: RAMAIYAH & SUBRAMANIAN BAYLIS ARCHITECTS 7466 E MERCER WAY 10801 MAIN ST, #110 MERCER ISLAND, WA 98040 BELLEVUE, WA 98004

APPLICANT/ARCHITECT: BRANDB@BAYLISARCHITECTS.COM PHONE: 425.392.5351 425-679-5202

CIVIL ENGINEER: EASTSIDE CONSULTANTS, INC 1320 NW MALL STREET, STE B ISSAQUAH, WA 98027 CONTACT: RONALD FREDERIKSEN

		CATION: N.R. <b>5</b> E	
S. FRED WIN			JOB NO. 24014
S & O N O T			DATE 3/24
			SCALE 1"=10'
			DESIGNED R.S.F.
A 39053 A .: A	(.3		DRAWN J.W.T.
CONSTERT.			CHECKED R.S.F.
MINING OVAL ENGLAND			APPROVED R.S.F.
3/7/2024		/ / /	SHEET <u>5</u> OF <u>14</u>

ร

Σ

6

S

**X** 

**M** 

5

S

S

C Ш Ш Z

5 Ζ 

IYAH 7466 IERCER

NC

Z

5

O

TSIDE MALL ST. SUIT

**TESC CALLOUTS** 

PRESERVING NATURAL VEGETATION
 PER BMP C101

- (6) TEMPORARY AND PERMANENT SEEDING PER BMP C120
- $\langle 7 \rangle$  MULCHING PER BMP C121

(8) NETS AND BLANKETS PER BMP C122 (9) PLASTIC COVERING PER BMP C123

(10) SURFACE ROUGHENING PER BMP C130

(1) GRADIENT TERRACES PER BMP C131

(12) STORM DRAIN INLET PROTECTION PER BMP C220


(13) CONCRETE HANDLING PER BMP C151

(14) SAWCUTTING AND SURFACING POLLUTION PREVENTION PER BMP C152

(15) MATERIAL DELIVERY, STORAGE, AND CONTAINMENT PER BMP C153

(16) MATERIALS ON HAND PER BMP C150

TREES TO BE REMOVED



1. As acceptable alternatives to the rebar shown in the PRECAST BASE SECTION, fibers (placed according to the Standard Specifications), or wire mesh having a minimum area of 0.12 square inches per foot shall be used with the minimum required rebar shown in the ALTERNATIVE PRECAST BASE SECTION. Wire mesh shall not be placed in the knockouts.


2. The knockout diameter shall not be greater than 20" (in). Knockouts shall have a wall thickness of 2" (in) minimum to 2.5" (in) maximum. Provide a 1.5" (in) minimum gap between the knockout wall and the outside of the pipe. After the pipe is installed, fill the gap with joint mortar in accordance with Standard Specification Section 9-04.3.

3. The maximum depth from the finished grade to the lowest pipe invert shall be 5' (ft).

4. The frame and grate may be installed with the flange down, or integrally cast into the adjustment section with flange up.

5. The Precast Base Section may have a rounded floor, and the walls may be sloped at a rate of 1 : 24 or steeper.


6. The opening shall be measured at the top of the Precast Base Section. 7. All pickup holes shall be grouted full after the basin has been placed.




Julie Heilman Julie Heilman 2020.09.01 07:52:50 -07'00' **CATCH BASIN TYPE 1** 

STANDARD PLAN B-5.20-03 SHEET 1 OF 1 SHEET

APPROVED FOR PUBLICATION Roark, Steve Digitally signed by Roark, Steve Date: 2020.09.09 09:45:23 -07'00' STATE DESIGN ENGINEER Washington State Department of Transportatio







PIPE ALLOWA	NCES
PIPE MATERIAL	MAXIMUM INSIDE DIAMETER (INCHES)
REINFORCED OR PLAIN CONCRETE	12"
ALL METAL PIPE	15"
CPSSP * (STD. SPEC. SECT. 9-05.20)	12"
POLYPROPYLENE (STD. SPEC. SECT. 9-05.24)	12"
SOLID WALL PVC (STD. SPEC. SECT. 9-05.12(1))	15"
PROFILE WALL PVC (STD. SPEC. SECT. 9-05.12(2))	15"
	ENE


\* CORRUGATED POLYETHYLENE STORM SEWER PIPE


RECTANGULAR ADJUSTMENT SECTION




PRECAST BASE SECTION









. . . .



**TYPICAL ORIENTATION** FOR ACCESS AND STEPS




**ECCENTRIC CONE SECTION** 



30"

48"

48"




Carpenter, Jeff Mar 2 2018 10:01 AM 111 Grant STATE DESIGN ENGINEER Washington State Department of Transportation




# REVIS S G DRAINA DETA Ζ Z AMA WAY SUBR/ RCER \ AN IYAH 7466 0 Ζ S U JOB NO. 24014 DATE 3/24 SCALE 1"=20' DESIGNEDRSF DRAWN RSF CHECKED RSF APPROVED RSF SHEET 6 OF 14

### NOTES

- 1. As acceptable alternatives to the rebar shown in the PRECAST BASE SECTION, fibers (placed according to the Standard Specifications), or wire mesh having a minimum area of 0.12 square inches per foot shall be used with the minimum required rebar shown in the ALTERNATIVE PRECAST BASE SECTION. Wire mesh shall not be placed in the knockouts.
- 2. The knockout diameter shall not be greater than 18" (in) . Knockouts shall have a wall thickness of 2" (in) minimum to 2.5" (in) maximum. Provide a 1.5" (in) minimum gap between the knockout wall and the outside of the pipe. After the pipe is installed, Fill the gap with joint mortar in accordance with Standard Specification Section 9-04.3.
- 3. The maximum depth from the finished grade to the lowest pipe invert shall be 5' (ft).
- 4. The frame and grate may be installed with the flange up or down. The frame may be cast into the adjustment section.
- 5. The Precast Base Section may have a rounded floor, and the walls may be sloped at a rate of 1 : 24 or steeper.
- 6. The opening shall be measured at the top of the precast base section.
- 7. All pickup holes shall be grouted full after the inlet has been placed.
- 8. Pipe allowances will vary depending on pipe material used. Contact the Region Hydraulic Engineer for assistance.





STANDARD PLAN B-25.60-03

SHEET 1 OF 1 SHEET

APPROVED FOR PUBLICATION


Aug 23, 2023

STATE DESIGN ENGINEE

Mach a Doines


Washington State Department of Transportation


ALTERNATIVE PRECAST BASE SECTION (SEE NOTE 1)





**RECTANGULAR ADJUSTMENT SECTION** 

Julie Hilmon Heilman, Julie Jan 25 2017 3:01 PM **MISCELLANEOUS DETAILS** FOR **DRAINAGE STRUCTURES** STANDARD PLAN B-30.90-02 SHEET 1 OF 1 SHEET APPROVED FOR PUBLICATION E Jul for Carpenter, Jeff Jan 26 2017 6:52 AM STATE DESIGN ENGINEER









2019 Stormwater Management Manual for Western Washington Volume II - Chapter 3 - Page 279

limitation of liability, and disclaime

State of Washington

vent future erosion. Perform street cleaning at the end of each day or more often if necessary.

**BMP C120: Temporary and Permanent Seeding** 

Purpose

Seeding reduces erosion by stabilizing exposed soils. A well-established vegetative cover is one of the most effective methods of reducing erosion.

Conditions of Use

remain unworked for more than 30 days.

1 through October 1.

until 75 percent grass cover is established.

Review all disturbed areas in late August to early September and complete all seeding by the end of September. Otherwise, vegetation will not establish itself enough to provide more than average protection.

Mulch is required at all times for seeding because it protects seeds from heat, moisture loss, and transport due to runoff. Mulch can be applied on top of the seed or simultaneously by hydroseeding. See BMP C121: Mulching for specifications.

Seed and mulch all disturbed areas not otherwise vegetated at final site stabilization. Final stabilization means the completion of all soil disturbing activities at the site and the establishment of a permanent vegetative cover, or equivalent permanent stabilization measures (such as pavement, riprap, gabions, or geotextiles) which will prevent erosion. See BMP T5.13: Post-Construction Soil Quality and Depth.

Design and Installation Specifications

# General

 Install channels intended for vegetation before starting major earthwork and hydroseed with a Bonded Fiber Matrix. For vegetated channels that will have high flows, install erosion control blankets over the top of hydroseed. Before allowing water to flow in vegetated channels, establish 75 percent vegetation cover. If vegetated channels cannot be established by seed

> 2019 Stormwater Management Manual for Western Washington Volume II - Chapter 3 - Page 284

**Table II-3.2: Stabilized Construction Access** Geotextile Standards (continued)

stile Standards (continued)					
Property	Required Value				
ion (ASTM D4632)	30% max.				
n (ASTM D3786-80a)	400 psi min.				
	20-45 (U.S. standard sieve size)				

• Consider early installation of the first lift of asphalt in areas that will be paved; this can be used as a stabilized access. Also consider the installation of excess concrete as a stabilized access. During large concrete pours, excess concrete is often available for this purpose.

• Fencing (see BMP C103: High-Visibility Fence) shall be installed as necessary to restrict

• Whenever possible, the access shall be constructed on a firm, compacted subgrade. This can substantially increase the effectiveness of the pad and reduce the need for maintenance.

 Construction accesses should avoid crossing existing sidewalks and back of walk drains if at all possible. If a construction access must cross a sidewalk or back of walk drain, the full length of the sidewalk and back of walk drain must be covered and protected from sediment leaving

WSDOT has raised safety concerns about the Quarry Spall rock specified above. WSDOT observes that the 4-inch to 8-inch rock sizes can become trapped between Dually truck tires, and then released off-site at highway speeds. WSDOT has chosen to use a modified specification for the rock while continuously verifying that the Stabilized Construction Access remains effective. To remain effective, the BMP must prevent sediment from migrating off site. To date, there has been no performance testing to verify operation of this new specification. Jurisdictions may use the alternative specification, but must perform increased off-site inspection if they use, or allow others to use, it.

Stabilized Construction Accesses may use material that meets the requirements of WSDOT's Standard Specifications for Road, Bridge, and Municipal Construction Section 9-03.9(1) (WSDOT, 2016)

The grading and quality requirements are listed in Table II-3.3: Stabilized Construction Access

**Table II-3.3: Stabilized Construction Access** 

**Alternative Material** Requirements

Sieve Size	Percent Passing
/ <del>/</del> 2	99-100
	204 -

2019 Stormwater Management Manual for Western Washington

**Table II-3.3: Stabilized Construction Access Alternative Material** Requirements

(continued)			
Sieve Size	Percent Passing		
2″	65-100		
3/4"	40-80		
No. 4	5 max.		
No. 100	0-2		
% Fracture	75 min.		

All percentages are by weight.

- The sand equivalent value and dust ratio requirements do not apply.
- The fracture requirement shall be at least one fractured face and will apply the combined aggregate retained on the No. 4 sieve in accordance with FOP for AASHTO T 335.

Maintenance Standards

- Quarry spalls shall be added if the pad is no longer in accordance with the specifications.
- If the access is not preventing sediment from being tracked onto pavement, then alternative measures to keep the streets free of sediment shall be used. This may include replacement/cleaning of the existing quarry spalls, street sweeping, an increase in the dimensions of the access, or the installation of BMP C106: Wheel Wash.
- Any sediment that is tracked onto pavement shall be removed by shoveling or street sweeping. The sediment collected by sweeping shall be removed or stabilized on site. The pavement shall not be cleaned by washing down the street, except when high efficiency sweeping is ineffective and there is a threat to public safety. If it is necessary to wash the streets, the construction of a small sump to contain the wash water shall be considered. The sediment would then be washed into the sump where it can be controlled.
- Perform street sweeping by hand or with a high efficiency sweeper. Do not use a non-high efficiency mechanical sweeper because this creates dust and throws soils into storm systems or conveyance ditches.
- Any quarry spalls that are loosened from the pad, which end up on the roadway shall be removed immediately.
- . If vehicles are entering or exiting the site at points other than the construction access(es), BMP C103: High-Visibility Fence shall be installed to control traffic.

2019 Stormwater Management Manual for Western Washington Volume II - Chapter 3 - Page 277

Crushed rock, gravel base, etc., shall be added as required to maintain a stable driving surface and

Following construction, these areas shall be restored to pre-construction condition or better to pre-

Use seeding throughout the project on disturbed areas that have reached final grade or that will

The optimum seeding windows for western Washington are April 1 through June 30 and September

Between July 1 and August 30 seeding requires irrigation until 75 percent grass cover is established. Between October 1 and March 30 seeding requires a cover of mulch or an erosion control blanket

before water flow; install sod in the channel bottom - over top of hydromulch and erosion control blankets.

- Confirm the installation of all required surface water control measures to prevent seed from washing away.
- Hydroseed applications shall include a minimum of 1,500 pounds per acre of mulch with 3 percent tackifier. See BMP C121: Mulching for specifications.
- Areas that will have seeding only and not landscaping may need compost or meal-based mulch included in the hydroseed in order to establish vegetation. Re-install native topsoil on the disturbed soil surface before application. See BMP T5.13: Post-Construction Soil Quality and Depth.
- When installing seed via hydroseeding operations, only about 1/3 of the seed actually ends up in contact with the soil surface. This reduces the ability to establish a good stand of grass quickly. To overcome this, consider increasing seed quantities by up to 50 percent.
- Enhance vegetation establishment by dividing the hydromulch operation into two phases: • Phase 1- Install all seed and fertilizer with 25-30 percent mulch and tackifier onto soil in the first lift.
- Phase 2- Install the rest of the mulch and tackifier over the first lift.
- Or, enhance vegetation by:
- Installing the mulch, seed, fertilizer, and tackifier in one lift.
- Spread or blow straw over the top of the hydromulch at a rate of 800-1000 pounds per
- Hold straw in place with a standard tackifier.

Both of these approaches will increase cost moderately but will greatly improve and enhance vegetative establishment. The increased cost may be offset by the reduced need for:

- Irrigation.
- Reapplication of mulch.
- Repair of failed slope surfaces.

This technique works with standard hydromulch (1,500 pounds per acre minimum) and Bonded Fiber Matrix/ Mechanically Bonded Fiber Matrix (BFM/MBFMs) (3,000 pounds per acre minimum).

- Seed may be installed by hand if:
- Temporary and covered by straw, mulch, or topsoil.
- Permanent in small areas (usually less than 1 acre) and covered with mulch, topsoil, or
- erosion blankets.
- The seed mixes listed in Table II-3.4: Temporary and Permanent Seed Mixes include

2019 Stormwater Management Manual for Western Washington

Volume II - Chapter 3 - Page 285

<ul> <li>Upon project completi manent access for ma</li> </ul>	on and site stabilization, all intenance shall be permane	construction accesse ently stabilized.	es intended as per-	REVISIONS BY DAT	© THE PLANS SET FORTH ON THIS SHEET ARE AND SHALL © REMAIN THE PROPERTY OF EASTSIDE CONSULTANTS, INC.
				TESC DETAILS	
recommended mixes f <ul> <li>Apply these mixes, wit</li> </ul>	water Management Manua Volume II - Chapter 3 - or both temporary and perr h the exception of the wet a	Page 278 nanent seeding. rea seed mix, at a ra	te of 120 pounds per	RAMAIYAH AND SUBRAMANIAN 7466 E. MERCER WAY	MERCER ISLAND, WA 98040
acre. This rate can be the wet area seed mix   Consult the local supple appropriate mix depending on the soil to traff depending on the soil to traff.  Chewings or annual blue grass Perennial rye Redtop or colonial bentgrass White dutch clover Trifolium Perennial rye blend Lolium perennial rye blend Chewings and red fescue blend A turf seed mix for dry situate (several varieties) Dwarf tall fescue (several varieties) Dwarf perennial Lolium perennial rye (Barclay) Red fescue Festuca Agrostis Colonial bentgrass Agrostis A seed Tall or meadow fes-	reduced if soil amendments at a rate of 60 pounds per a iers or the local conservation ds on a variety of factors, in ic. Alternative seed mixes a ype and hydrology of the ar is <b>Temporary and Po</b> Name % Weight <b>Temporary Erosion Conf</b> rd mix for areas requiring a ter rubra var. ata or Poa 40 erenne 50 alba or tenuis 5 repens 5 Landscaping See A recommended mix for land erenne 70 rubra var. ata or Fes- a 30 a Low-Growing Turf S ons where there is no need fo tenance. arundin- 45 erenne 30 rubra 20 tenuis 5 Bioswale Seed I mix for bioswales and other in	s or slow-release fertion incre. on district for their reconcluding location, exp pproved by the local ea. ermanent Seed % Purity rol Seed Mix nporary vegetative cov 98 98 98 98 98 98 98 98 98 98	ilizers are used. Apply commendations. The osure, soil type, slope, authority may be used, I Mixes 90 90 90 90 85 90 90 90 90 90 90 90 90 90 90 90 90 90	ENGINEERS - SURVEYORS	EASTSIDE CONSULTANTS, INC. 1320 N.W. MALL ST., SUITE B ISSAQUAH, WASHINGTON 98027 PH:(425)392-5351 FAX:392-4676

3/7/2024

SCALE 1"=20' DESIGNED J.W.T. DRAWN J.W.T. CHECKED R.S.F. APPROVED R.S.F.

### Table II-3.4: Temporary and Permanent Seed Mixes (continued) Common Name Latin Name % Weight % Purity % Germination

acea or Festura

cue	acea or Festuca elatior	a 1 a 1 2		
Seaside/Creeping bentgrass	Agrostis palustris	10-15	92	85
Redtop bentgrass	Agrostis alba or Agrostis gigantea	5-10	90	80
		Wet Area Seed Mix		•
		ed mix appropriate for ermit Authority (HPA)		
Tall or meadow fes-	Festuca arundin-			
cue	acea or Festuca elatior	60-70	98	90
		60-70 10-15	98 98	90 85
cue Seaside/Creeping	elatior			
cue Seaside/Creeping bentgrass	elatior Agrostis palustris Alepocurus praten-	10-15	98	85
cue Seaside/Creeping bentgrass Meadow foxtail	elatior Agrostis palustris Alepocurus praten- sis	10-15 10-15	98 90	85 80

onization by native plants is desirable. Likely applications include rural road and utility right-of-way. Seeding should take place in September or very early October in order to obtain adequate establishment prior to the winter months. Consider the appropriateness of clover, a fairly invasive species, in the mix. Amending the soil can reduce the need for clover

	Redtop or Oregon bentgrass	Agrostis alba or Agrostis ore- gonensis	20	92	85
100000	Red fescue	Festuca rubra	70	98	90
	White dutch clover	Trifolium repens	10	98	90

Roughening and Rototilling

- The seedbed should be firm and rough. Roughen all soil no matter what the slope. Track walk slopes before seeding if engineering purposes require compaction. Backblading or smoothing of slopes greater than 4H:1V is not allowed if they are to be seeded.
- Restoration-based landscape practices require deeper incorporation than that provided by a simple single-pass rototilling treatment. Wherever practical, initially rip the subgrade to improve long-term permeability, infiltration, and water inflow qualities. At a minimum,

2019 Stormwater Management Manual for Western Washington Volume II - Chapter 3 - Page 287

compost;

or blends of these.

Tackifier shall be plant-based, such as guar or alpha plantago, or chemical-based such as polyacrylamide or polymers.

Generally, mulches come in 40-50 pound bags. Seed and fertilizer are added at time of application. Recycled cellulose may contain polychlorinated biphenyl (PCBs). Ecology recommends that products should be evaluated for PCBs prior to use.

Refer to BMP C126: Polyacrylamide (PAM) for Soil Erosion Protection for conditions of use. PAM shall not be directly applied to water or allowed to enter a water body.

Any mulch or tackifier product used shall be installed per the manufacturer's instructions.

Design and Installation Specifications

For mulch materials, application rates, and specifications, see Table II-3.6: Mulch Standards and Guidelines. Consult with the local supplier or the local conservation district for their recommendations. Increase the application rate until the ground is 95% covered (i.e. not visible under the mulch layer). Note: Thickness may be increased for disturbed areas in or near sensitive areas or other areas highly susceptible to erosion.

Where the option of "Compost" is selected, it should be a coarse compost that meets the size gradations listed in Table II-3.5: Size Gradations of Compost as Mulch Material when tested in accordance with Test Method 02.02-B found in Test Methods for the Examination of Composting and Compost (Thompson, 2001).

Table II-3.5: Size Gradations of Compost as Mulch Material

Sieve Size	Percent Passing	
3"	100%	
1"	90% - 100%	
3/4"	70% - 100%	
1/4"	40% - 100%	

Mulch used within the ordinary high-water mark of surface waters should be selected to minimize potential flotation of organic matter. Composted organic materials have higher specific gravities (densities) than straw, wood, or chipped material. Consult the Hydraulic Permit Authority (HPA) for mulch mixes if applicable.

Maintenance Standards

The thickness of the mulch cover must be maintained.

Any areas that experience erosion shall be remulched and/or protected with a net or blanket. If the erosion problem is drainage related, then the problem shall be fixed and the eroded area remulched.

2019 Stormwater Management Manual for Western Washington

Volume II - Chapter 3 - Page 290

# **Fertilizers**

- This will prevent the over-application of fertilizer.
- nitrogen.

# Bonded Fiber Matrix and Mechanically Bonded Fiber Matrix

- fertilizer.
- establishment. Advantages over blankets include:

- for safety.

# Table II-3.6 Mulch Mater-Guideline ial Quality Standards Application Rates Straw Remarks Quality Standards Application Rates Hvdromulc Remarks Application Rates Compost Remarks conditions. Do not use near wetlands or near phosphorous impaired water Quality Chipped Standards Site Vegetation Application Rates

permanent areas shall use soil amendments to achieve organic matter and permeability performance defined in engineered soil/landscape systems. For systems that are deeper than 8 inches complete the rototilling process in multiple lifts, or prepare the engineered soil system per specifications and place to achieve the specified depth.

• Conducting soil tests to determine the exact type and quantity of fertilizer is recommended.

• Organic matter is the most appropriate form of fertilizer because it provides nutrients (including nitrogen, phosphorus, and potassium) in the least water-soluble form.

• In general, use 10-4-6 N-P-K (nitrogen-phosphorus-potassium) fertilizer at a rate of 90 pounds per acre. Always use slow-release fertilizers because they are more efficient and have fewer environmental impacts. Do not add fertilizer to the hydromulch machine, or agitate, more than 20 minutes before use. Too much agitation destroys the slow-release coating.

• There are numerous products available that take the place of chemical fertilizers. These include several with seaweed extracts that are beneficial to soil microbes and organisms. If 100 percent cottonseed meal is used as the mulch in hydroseed, chemical fertilizer may not be necessary. Cottonseed meal provides a good source of long-term, slow-release, available

• On steep slopes use Bonded Fiber Matrix (BFM) or Mechanically Bonded Fiber Matrix (MBFM) products. Apply BFM/MBFM products at a minimum rate of 3,000 pounds per acre with approximately 10 percent tackifier. Achieve a minimum of 95 percent soil coverage during application. Numerous products are available commercially. Most products require 24-36 hours to cure before rainfall and cannot be installed on wet or saturated soils. Generally, products come in 40-50 pound bags and include all necessary ingredients except for seed and

## Install products per manufacturer's instructions.

• BFMs and MBFMs provide good alternatives to blankets in most areas requiring vegetation

• BFM and MBFMs do not require surface preparation.

• Helicopters can assist in installing BFM and MBFMs in remote areas.

• On slopes steeper than 2.5H:1V, blanket installers may require ropes and harnesses

• Installing BFM and MBFMs can save at least \$1,000 per acre compared to blankets.

2019 Stormwater Management Manual for Western Washington

Volume II - Chapter 3 - Page 288

6:	Mulch	Standards	and	Guidelines	
----	-------	-----------	-----	------------	--

Description
-dried; free from undesirable seed and coarse material.
3" thick; 5 bales per 1,000 sf or 2-3 tons per acre
st-effective protection when applied with adequate thickness. Hand- plication generally requires greater thickness than blown straw. The ckness of straw may be reduced by half when used in conjunction with eding. In windy areas straw must be held in place by crimping, using a skifier, or covering with netting. Blown straw always has to be held in ce with a tackifier as even light winds will blow it away. Straw, however, s several deficiencies that should be considered when selecting mulch iterials. It often introduces and/or encourages the propagation of weed accies and it has no significant long-term benefits It should also not be

used within the ordinary high-water elevation of surface waters (due to flot-No growth inhibiting factors.

Approx. 35-45 lbs per 1,000 sf or 1,500 - 2,000 lbs per acre

Shall be applied with hydromulcher. Shall not be used without seed and

tackifier unless the application rate is at least doubled. Fibers longer than about 3/4 - 1 inch clog hydromulch equipment. Fibers should be kept to less than 3/4 inch.

Quality No visible water or dust during handling. Must be produced per WAC 173-Standards 350, Solid Waste Handling Standards, but may have up to 35% biosolids. 2" thick min.; approx. 100 tons per acre (approx. 750 lbs per cubic yard)

More effective control can be obtained by increasing thickness to 3". Excellent mulch for protecting final grades until landscaping because it can be directly seeded or tilled into soil as an amendment. Compost used for mulch has a coarser size gradation than compost used for BMP C125: Topsoiling / Composting or BMP T5.13: Post-Construction Soil Quality and Depth. It is more stable and practical to use in wet areas and during rainy weather

Gradations from fines to 6 inches in length for texture, variation, and interlocking properties. Include a mix of various sizes so that the average size is between 2- and 4- inches.

2" thick min.;

## 2019 Stormwater Management Manual for Western Washington

Volume II - Chapter 3 - Page 291

### Maintenance Standards

Reseed any seeded areas that fail to establish at least 75 percent cover (100 percent cover for areas that receive sheet or concentrated flows). If reseeding is ineffective, use an alternate method such as sodding, mulching, nets, or blankets.

- Reseed and protect by mulch any areas that experience erosion after achieving adequate cover. Reseed and protect by mulch any eroded area.
- Supply seeded areas with adequate moisture, but do not water to the extent that it causes run-

## Approved as Functionally Equivalent

Ecology has approved products as able to meet the requirements of this BMP. The products did not pass through the Technology Assessment Protocol - Ecology (TAPE) process. Local jurisdictions may choose not to accept these products, or may require additional testing prior to consideration for local use. Products that Ecology has approved as functionally equivalent are available for review on Ecology's website at:

https://ecology.wa.gov/Regulations-Permits/Guidance-technical-assistance/Stormwater-permittee-guidance-resources/Emerging-stormwater-treatment-technologies

# **BMP C121: Mulching**

## Purpose

Mulching soils provides immediate temporary protection from erosion. Mulch also enhances plant establishment by conserving moisture, holding fertilizer, seed, and topsoil in place, and moderating soil temperatures. There are a variety of mulches that can be used. This section discusses only the most common types of mulch.

## Conditions of Use

As a temporary cover measure, mulch should be used:

- For less than 30 days on disturbed areas that require cover.
- At all times for seeded areas, especially during the wet season and during the hot summer months.

• During the wet season on slopes steeper than 3H:1V with more than 10 feet of vertical relief. Mulch may be applied at any time of the year and must be refreshed periodically.

- For seeded areas, mulch may be made up of 100 percent:
- cottonseed meal;
- fibers made of wood, recycled cellulose, hemp, or kenaf;

2019 Stormwater Management Manual for Western Washington Volume II - Chapter 3 - Page 289

### Table II-3.6: Mulch Standards and Guidelines (continued) Mulch Mater

Mulch Mater- ial	Guideline	Description
	Remarks	This is a cost-effective way to dispose of debris from clearing and grub- bing, and it eliminates the problems associated with burning. Generally, it should not be used on slopes above approx. 10% because of its tendency to be transported by runoff. It is not recommended within 200 feet of sur- face waters. If permanent seeding or planting is expected shortly after mulch, the decomposition of the chipped vegetation may tie up nutrients important to grass establishment.
		Note: thick application of this material over existing grass, herbaceous species, and some groundcovers could smother and kill vegetation.
	Quality Standards	No visible water or dust during handling. Must be purchased from a supplier with a Solid Waste Handling Permit or one exempt from solid waste regulations.
Wood-	Application Rates	2" thick min.; approx. 100 tons per acre (approx. 750 lbs. per cubic yard)
Based Mulch	Remarks	This material is often called "wood straw" or "hog fuel". The use of mulch ultimately improves the organic matter in the soil. Special caution is advised regarding the source and composition of wood-based mulches. Its preparation typically does not provide any weed seed control, so evidence of residual vegetation in its composition or known inclusion of weed plants or seeds should be monitored and prevented (or minimized).
	Quality Standards	A blend of loose, long, thin wood pieces derived from native conifer or deciduous trees with high length-to-width ratio.
	Application Rates	2" thick min.
Wood Strand Mulch	Remarks	Cost-effective protection when applied with adequate thickness. A min- imum of 95-percent of the wood strand shall have lengths between 2 and 10-inches, with a width and thickness between 1/16 and 1/2-inches. The mulch shall not contain resin, tannin, or other compounds in quantities that would be detrimental to plant life. Sawdust or wood shavings shall not be used as mulch. [Specification 9-14.4(4) from the <i>Standard Specifications</i> <i>for Road, Bridge, and Municipal Construction</i> (WSDOT, 2016)

**BMP C122: Nets and Blankets** 

Purpose

Erosion control nets and blankets are intended to prevent erosion and hold seed and mulch in place on steep slopes and in channels so that vegetation can become well established. In addition, some nets and blankets can be used to permanently reinforce turf to protect drainage ways during high flows

2019 Stormwater Management Manual for Western Washington

Volume II - Chapter 3 - Page 292



3/7/2024

**BMP C123: Plastic Covering** 

can convey clean water away from these areas.

removal, and disposal add to the total costs of this BMP.

plastic covered slope with dirty runoff from a project.

• Pond liner in temporary sediment pond.

Design and Installation Specifications

Plastic slope cover must be installed as follows:

• Emergency slope protection during heavy rains.

Temporary drainpipe ("elephant trunk") used to direct water.

1. Run plastic up and down the slope, not across the slope.

Other uses for plastic include:

being stored.

• Temporary ditch liner.

# Purpose

Plastic covering provides immediate, short-term erosion protection to slopes and disturbed areas.

Conditions of Use

Plastic covering may be used on disturbed areas that require cover measures for less than 30 days,


except as stated below.

- Plastic is particularly useful for protecting cut and fill slopes and stockpiles. However, the rel-
- atively rapid breakdown of most polyethylene sheeting makes it unsuitable for applications greater than six months.
- might be adversely impacted by concentrated runoff. Such areas include steep and/or
- Due to rapid runoff caused by plastic covering, do not use this method upslope of areas that
- unstable slopes.

• To prevent undercutting, trench and backfill rolled plastic covering products.

- Plastic sheeting may result in increased runoff volumes and velocities, requiring additional on-

- site measures to counteract the increases. Creating a trough with wattles or other material



Although the plastic material is inexpensive to purchase, the cost of installation, maintenance,

Whenever plastic is used to protect slopes, install water collection measures at the base of the

• Liner for bermed temporary fuel storage area if plastic is not reactive to the type of fuel

2. Plastic may be installed perpendicular to a slope if the slope length is less than 10 feet.

2019 Stormwater Management Manual for Western Washington

Volume II - Chapter 3 - Page 298

slope. These measures include plastic-covered berms, channels, and pipes used to convey clean rainwater away from bare soil and disturbed areas. Do not mix clean runoff from a

- 3. Provide a minimum of 8-inch overlap at the seams.
- 4. On long or wide slopes, or slopes subject to wind, tape all seams.
- 5. Place plastic into a small (12-inch wide by 6-inch deep) slot trench at the top of the slope and backfill with soil to keep water from flowing underneath.
- 6. Place sand filled burlap or geotextile bags every 3 to 6 feet along seams and tie them
- together with twine to hold them in place.
- 7. Inspect plastic for rips, tears, and open seams regularly and repair immediately. This prevents high velocity runoff from contacting bare soil, which causes extreme erosion.
- 8. Sandbags may be lowered into place tied to ropes. However, all sandbags must be staked in place.
- Plastic sheeting shall have a minimum thickness of 0.06 millimeters.
- If erosion at the toe of a slope is likely, a gravel berm, riprap, or other suitable protection shall be installed at the toe of the slope in order to reduce the velocity of runoff.

Maintenance Standards

- Torn sheets must be replaced and open seams repaired.
- Completely remove and replace the plastic if it begins to deteriorate due to ultraviolet radi-
- Completely remove plastic when no longer needed.
- Dispose of old tires used to weight down plastic sheeting appropriately.

Approved as Functionally Equivalent

Ecology has approved products as able to meet the requirements of this BMP. The products did not pass through the Technology Assessment Protocol – Ecology (TAPE) process. Local jurisdictions may choose not to accept these products, or may require additional testing prior to consideration for local use. Products that Ecology has approved as functionally equivalent are available for review on Ecology's website at:

https://ecology.wa.gov/Regulations-Permits/Guidance-technical-assistance/Stormwater-permittee-guidance-resources/Emerging-stormwater-treatment-technologies

## BMP C124: Sodding

### Purpose

The purpose of sodding is to establish turf for immediate erosion protection and to stabilize drainage paths where concentrated overland flow will occur.

> 2019 Stormwater Management Manual for Western Washington Volume II - Chapter 3 - Page 299

Design and Installation Specifications

- Vacuum slurry and cuttings during cutting and surfacing operations.
- Slurry and cuttings shall not remain on permanent concrete or asphalt pavement overnight.
- Slurry and cuttings shall not drain to any natural or constructed drainage conveyance includ-
- ing stormwater systems. This may require temporarily blocking catch basins. • Dispose of collected slurry and cuttings in a manner that does not violate ground water or sur-
- face water quality standards. · Do not allow process water generated during hydro-demolition, surface roughening or similar
- operations to drain to any natural or constructed drainage conveyance including stormwater systems. Dispose of process water in a manner that does not violate ground water or surface water quality standards.
- Handle and dispose of cleaning waste material and demolition debris in a manner that does not cause contamination of water. Dispose of sweeping material from a pick-up sweeper at an appropriate disposal site.

Maintenance Standards

Continually monitor operations to determine whether slurry, cuttings, or process water could enter waters of the state. If inspections show that a violation of water quality standards could occur, stop operations and immediately implement preventive measures such as berms, barriers, secondary containment, and/or vacuum trucks.

# BMP C153: Material Delivery, Storage, and Containment

# Purpose

Prevent, reduce, or eliminate the discharge of pollutants to the stormwater system or watercourses from material delivery and storage. Minimize the storage of hazardous materials on-site, store materials in a designated area, and install secondary containment.

### Conditions of Use

Use at construction sites with delivery and storage of the following materials:

- · Petroleum products such as fuel, oil and grease
- Soil stabilizers and binders (e.g., Polyacrylamide)
- Fertilizers, pesticides and herbicides
- Detergents
- Asphalt and concrete compounds

2019 Stormwater Management Manual for Western Washington Volume II - Chapter 3 - Page 318

- pipe, sandbags, geotextile fabric and steel "T" posts.
- that are available for use on several projects.
- If storage space at the project site is at a premium, the contractor could maintain the materials at their office or yard. The office or yard must be less than an hour from the project site.

# Design and Installation Specifications

- Clear Plastic, 6 mil
- Drainpipe, 6 or 8 inch diameter
- Sandbags, filled
- Straw Bales for mulching
- Quarry Spalls
- Washed Gravel
- Geotextile Fabric
- Catch Basin Inserts
- Steel "T" Posts
- Silt fence material
- Straw Wattles

# Maintenance Standards

- All materials with the exception of the quarry spalls, steel "T" posts, and gravel should be kept covered and out of both sun and rain.
- Re-stock materials as needed. **BMP C151: Concrete Handling**

### Purpose

### thickness is 2 feet.

- For outlets at the base of steep slope pipes (pipe slope greater than 10 percent), use an engineered energy dissipator.
- Filter fabric or erosion control blankets should always be used under riprap to prevent scour and channel erosion. See BMP C122: Nets and Blankets.

# Maintenance Standards

- Inspect and repair as needed
- · Add rock as needed to maintain the intended function
- Clean energy dissipator if sediment builds up.

## Purpose

bilization of the disturbed area.

## Conditions of Use

trapping BMP.

18-inches of sod around each finished lawn and yard drain.

- Materials should be stockpiled and readily available before any site clearing, grubbing, or earthwork begins. A large contractor or project proponent could keep a stockpile of materials
- Depending on project type, size, complexity, and length, materials and quantities will vary. A good minimum list of items that will cover numerous situations includes:
- Concrete work can generate process water and slurry that contain fine particles and high pH, both of which can violate water quality standards in the receiving water. Concrete spillage or concrete discharge to waters of the State is prohibited. Use this BMP to minimize and eliminate concrete, concrete process water, and concrete slurry from entering waters of the State.
  - 2019 Stormwater Management Manual for Western Washington
    - Volume II Chapter 3 Page 315
- Bank stabilization, bioengineering, and habitat features may be required for disturbed areas. This work may require a Hydraulic Project Approval (HPA) from the Washington State Department of Fish and Wildlife. See I-2.11 Hydraulic Project Approvals.
- **BMP C220: Inlet Protection**
- Inlet protection prevents coarse sediment from entering drainage systems prior to permanent sta-
- Use inlet protection at inlets that are operational before permanent stabilization of the disturbed areas that contribute runoff to the inlet. Provide protection for all storm drain inlets downslope and within 500 feet of a disturbed or construction area, unless those inlets are preceded by a sediment
- Also consider inlet protection for lawn and yard drains on new home construction. These small and numerous drains coupled with lack of gutters can add significant amounts of sediment into the roof drain system. If possible, delay installing lawn and yard drains until just before landscaping, or cap these drains to prevent sediment from entering the system until completion of landscaping. Provide
- Table II-3.10: Storm Drain Inlet Protection lists several options for inlet protection. All of the methods for inlet protection tend to plug and require a high frequency of maintenance. Limit contributing drainage areas for an individual inlet to one acre or less. If possible, provide emergency overflows with additional end-of-pipe treatment where stormwater ponding would cause a hazard.
  - 2019 Stormwater Management Manual for Western Washington
    - Volume II Chapter 3 Page 356

# Conditions of Use

## Any time concrete is used, utilize these management practices. Concrete construction project components include, but are not limited to:

- Curbs
- Sidewalks
- Roads
- Bridges
- Foundations
- Floors
- Runways
- Disposal options for concrete, in order of preference are:
- 1. Off-site disposal
- 2. Concrete wash-out areas (see BMP C154: Concrete Washout Area)
- 3. De minimus washout to formed areas awaiting concrete
- Design and Installation Specifications
- Wash concrete truck drums at an approved off-site location or in designated concrete washout areas only. Do not wash out concrete trucks onto the ground (including formed areas awaiting concrete), or into storm drains, open ditches, streets, or streams. Refer to BMP C154: Concrete Washout Area for information on concrete washout areas.
- Return unused concrete remaining in the truck and pump to the originating batch plant for recycling. Do not dump excess concrete on site, except in designated concrete washout areas as allowed in BMP C154: Concrete Washout Area.
- Wash small concrete handling equipment (e.g. hand tools, screeds, shovels, rakes, floats, trowels, and wheelbarrows) into designated concrete washout areas or into formed areas awaiting concrete pour
- · At no time shall concrete be washed off into the footprint of an area where an infiltration feature will be installed.
- Wash equipment difficult to move, such as concrete paving machines, in areas that do not directly drain to natural or constructed stormwater conveyance or potential infiltration areas.
- Do not allow washwater from areas, such as concrete aggregate driveways, to drain directly (without detention or treatment) to natural or constructed stormwater conveyances.
- Contain washwater and leftover product in a lined container when no designated concrete washout areas (or formed areas, allowed as described above) are available. Dispose of contained concrete and concrete washwater (process water) properly.

2019 Stormwater Management Manual for Western Washington Volume II - Chapter 3 - Page 316

Type of Inlet Pro- tection	Emergency Overflow	Applicable for Paved/ Earthen Sur- faces	Conditions of Use
Drop Inlet Protect	ion		
Excavated drop inlet protection	Yes, temporary flooding may occur	Earthen	Applicable for heavy flows. Easy to maintain. Large area requirement: 30'x30'/acre
Block and gravel drop inlet pro- tection	Yes	Paved or Earthen	Applicable for heavy concentrated flows Will not pond.
Gravel and wire drop inlet pro- tection	No	Paved or Earthen	Applicable for heavy concentrated flows Will pond. Can withstand traffic.
Catch basin filters	Yes	Paved or Earthen	Frequent maintenance required.
Curb Inlet Protecti	on		
Curb inlet pro- tection with wooden weir	Small capacity overflow	Paved	Used for sturdy, more compact install- ation.
Block and gravel curb inlet pro- tection	Yes	Paved	Sturdy, but limited filtration.
Culvert Inlet Prote	ction		
Culvert inlet sed- iment trap	N/A	N/A	18 month expected life.

# **Design and Installation Specifications**

Excavated Drop Inlet Protection

Excavated drop inlet protection consists of an excavated impoundment around the storm drain inlet. Sediment settles out of the stormwater prior to entering the storm drain. Design and installation specifications for excavated drop inlet protection include:

- Provide a depth of 1-2 ft as measured from the crest of the inlet structure.
- Slope sides of excavation should be no steeper than 2H:1V.
- Minimum volume of excavation is 35 cubic yards.
- Shape the excavation to fit the site, with the longest dimension oriented toward the longest
- inflow area.
- Install provisions for draining to prevent standing water.
- Clear the area of all debris.

2019 Stormwater Management Manual for Western Washington

Volume II - Chapter 3 - Page 357

- Always use forms or solid barriers for concrete pours, such as pilings, within 15-feet of surface
- Refer to BMP C252: Treating and Disposing of High pH Water for pH adjustment require-
- Refer to the Construction Stormwater General Permit (CSWGP) for pH monitoring requirements if the project involves one of the following activities:
- Significant concrete work (as defined in the CSWGP).
- The use of soils amended with (but not limited to) Portland cement-treated base, cement kiln dust or fly ash.
- Discharging stormwater to segments of water bodies on the 303(d) list (Category 5) for high pH.

# Maintenance Standards

Check containers for holes in the liner daily during concrete pours and repair the same day.

# **BMP C152: Sawcutting and Surfacing Pollution**

# Prevention

# Purpose

Sawcutting and surfacing operations generate slurry and process water that contains fine particles and high pH (concrete cutting), both of which can violate the water quality standards in the receiving water. Concrete spillage or concrete discharge to waters of the State is prohibited. Use this BMP to minimize and eliminate process water and slurry created through sawcutting or surfacing from entering waters of the State.

# Conditions of Use

Utilize these management practices anytime sawcutting or surfacing operations take place. Sawcutting and surfacing operations include, but are not limited to:

- Sawing
- Coring
- Grinding
- Roughening
- Hydro-demolition
- Bridge and road surfacing
  - 2019 Stormwater Management Manual for Western Washington Volume II - Chapter 3 - Page 317
- Grade the approach to the inlet uniformly.
- · Drill weep holes into the side of the inlet.
- Protect weep holes with screen wire and washed aggregate.
- Seal weep holes when removing structure and stabilizing area.
- Build a temporary dike, if necessary, to the down slope side of the structure to prevent bypass

### **Block and Gravel Filter**

A block and gravel filter is a barrier formed around the inlet with standard concrete blocks and gravel. See Figure II-3.17: Block and Gravel Filter. Design and installation specifications for block gravel filters include:

- Provide a height of 1 to 2 feet above the inlet.
- Recess the first row of blocks 2-inches into the ground for stability.
- Support subsequent courses by placing a pressure treated wood 2x4 through the block open-
- Do not use mortar.
- Lay some blocks in the bottom row on their side to allow for dewatering the pool.
- Place hardware cloth or comparable wire mesh with <sup>1</sup>/<sub>2</sub>-inch openings over all block openings.
- Place gravel to just below the top of blocks on slopes of 2H:1V or flatter.
- An alternative design is a gravel berm surrounding the inlet, as follows:
  - Provide a slope of 3H:1V on the upstream side of the berm.
- Provide a slope of 2H:1V on the downstream side of the berm.
- Provide a 1-foot wide level stone area between the gravel berm and the inlet.
- Use stones 3 inches in diameter or larger on the upstream slope of the berm
- Use gravel <sup>1</sup>/<sub>2</sub>- to <sup>3</sup>/<sub>4</sub>-inch at a minimum thickness of 1-foot on the downstream slope of the berm.

2019 Stormwater Management Manual for Western Washington Volume II - Chapter 3 - Page 358




đ 0 S Ш


7 **U**, 

G

JOB NO. 24014 **DATE 3/24** SCALE 1"=20' DESIGNED J.W.T. DRAWN J.W.T. CHECKED R.S.F. APPROVED R.S.F.



2019 Stormwater Management Manual for Western Washington Volume II - Chapter 3 - Page 359



ond each side of the inlet structure.

# Catch Basin Filters

Catch basin filters are designed by manufacturers for construction sites. The limited sediment storage capacity increases the amount of inspection and maintenance required, which may be daily for heavy sediment loads. To reduce maintenance requirements, combine a catch basin filter with another type of inlet protection. This type of inlet protection provides flow bypass without overflow and therefore may be a better method for inlets located along active rights-of-way. Design and installation specifications for catch basin filters include:


- Provides 5 cubic feet of storage.
- Requires dewatering provisions.

# **Curb Inlet Protection with Wooden Weir**

Curb inlet protection with wooden weir is an option that consists of a barrier formed around a curb inlet with a wooden frame and gravel. Design and installation specifications for curb inlet protection with wooden weirs include:

- Use wire mesh with ½-inch openings.
- Use extra strength filter cloth.
- Construct a frame.
- · Attach the wire and filter fabric to the frame
- Place weight on the frame anchors.

De	sign and Installatio	n Specifications
	Use in combination with o	ther construction stormwater BMPs.
	Maximum slope steepnes	s (perpendicular to the silt fence line) 1H:1V.
	<ul> <li>Maximum sheet or overlar</li> </ul>	nd flow path length to the silt fence of 100 feet.
	Do not allow flows greater	than 0.5 cfs.
	are minimum average roll	meets the following standards. All geotextile properties listed belo values (i.e., the test result for any sampled roll in a lot shall meet o in <u>Table II-3.11: Geotextile Fabric Standards for Silt Fence</u> ):
	Table II-3.11: G	eotextile Fabric Standards for Silt Fence
	Geotextile Property	Minimum Average Roll Value
	Polymeric Mesh AOS (ASTM D4751)	<ul><li>0.60 mm maximum for slit film woven (#30 sieve).</li><li>0.30 mm maximum for all other geotextile types (#50 sieve).</li><li>0.15 mm minimum for all fabric types (#100 sieve).</li></ul>
	Water Permittivity (ASTM D4491)	0.02 sec <sup>-1</sup> minimum
	Grab Tensile Strength	180 lbs. Minimum for extra strength fabric.
	(ASTM D4632)	100 lbs minimum for standard strength fabric.
	Grab Tensile Strength (ASTM D4632)	30% maximum
	Ultraviolet Resistance (ASTM D4355)	70% minimum
7	safety fence, or jute mesh	geotextiles with wire mesh, chicken wire, 2-inch x 2-inch wire, to increase the strength of the geotextile. Silt fence materials are tic mesh backing attached.
		ntain ultraviolet ray inhibitors and stabilizers to provide a minimum usable construction life at a temperature range of 0°F to 120°F.
		legradable silt fence is available that is strong, long lasting, and ca oject is completed, if permitted by the local jurisdiction.
		<u>Fence</u> for standard silt fence details. Include the following Stand- construction plans and specifications:
	1. The Contractor shal the Plans.	l install and maintain temporary silt fences at the locations shown
	<ol> <li>Construct silt fences activities.</li> </ol>	in areas of clearing, grading, or drainage prior to starting those
	2019 Stormwa	ter Management Manual for Western Washington



2019 Stormwater Management Manual for Western Washington Volume II - Chapter 3 - Page 371

Gravel and wire mesh filters are gravel barriers placed over the top of the inlet. This method does not provide an overflow. Design and installation specifications for gravel and wire mesh filters include:

- Use a hardware cloth or comparable wire mesh with <sup>1</sup>/<sub>2</sub>-inch openings.
- Place wire mesh over the drop inlet so that the wire extends a minimum of 1-foot bey-
- Overlap the strips if more than one strip of mesh is necessary.
- Place coarse aggregate over the wire mesh.

• Provide at least a 12-inch depth of aggregate over the entire inlet opening and extend at least 18-inches on all sides.

 Provides a high-flow bypass that will not clog under normal use at a construction site. Insert the catch basin filter in the catch basin just below the grating.

• Pile coarse washed aggregate against the wire and fabric.

2019 Stormwater Management Manual for Western Washington

Volume II - Chapter 3 - Page 360

2019 Stormwater Management Manual for Western Washington Volume II - Chapter 3 - Page 372

### **Block and Gravel Curb Inlet Protection**

Block and gravel curb inlet protection is a barrier formed around a curb inlet with concrete blocks and gravel. See Figure II-3.18: Block and Gravel Curb Inlet Protection. Design and installation specifications for block and gravel curb inlet protection include:

Use wire mesh with <sup>1</sup>/<sub>2</sub>-inch openings.

- Place two concrete blocks on their sides abutting the curb at either side of the inlet opening. These are spacer blocks.
- Place a 2x4 stud through the outer holes of each spacer block to align the front blocks.
- Place blocks on their sides across the front of the inlet and abutting the spacer blocks.
- Place wire mesh over the outside vertical face.
- Pile coarse aggregate against the wire to the top of the barrier.

2019 Stormwater Management Manual for Western Washington Volume II - Chapter 3 - Page 361

- 3. The silt fence shall have a 2-feet min. and a 21/2-feet max. height above the original ground surface.
- 4. The geotextile fabric shall be sewn together at the point of manufacture to form fabric lengths as required. Locate all sewn seams at support posts. Alternatively, two sections of silt fence can be overlapped, provided that the overlap is long enough and that the adjacent silt fence sections are close enough together to prevent silt laden water from escaping through the fence at the overlap.
- 5. Attach the geotextile fabric on the up-slope side of the posts and secure with staples, wire, or in accordance with the manufacturer's recommendations. Attach the geotextile fabric to the posts in a manner that reduces the potential for tearing.
- 6. Support the geotextile fabric with wire or plastic mesh, dependent on the properties of the geotextile selected for use. If wire or plastic mesh is used, fasten the mesh securely to the up-slope side of the posts with the geotextile fabric up-slope of the mesh.
- 7. Mesh support, if used, shall consist of steel wire with a maximum mesh spacing of 2inches, or a prefabricated polymeric mesh. The strength of the wire or polymeric mesh shall be equivalent to or greater than 180 lbs. grab tensile strength. The polymeric mesh must be as resistant to the same level of ultraviolet radiation as the geotextile fabric it supports.
- 8. Bury the bottom of the geotextile fabric 4-inches min. below the ground surface. Backfill and tamp soil in place over the buried portion of the geotextile fabric, so that no flow can pass beneath the silt fence and scouring cannot occur. When wire or polymeric back-up support mesh is used, the wire or polymeric mesh shall extend into the ground 3-inches min.
- 9. Drive or place the silt fence posts into the ground 18-inches min. A 12-inch min. depth is allowed if topsoil or other soft subgrade soil is not present and 18-inches cannot be reached. Increase fence post min. depths by 6 inches if the fence is located on slopes of 3H:1V or steeper and the slope is perpendicular to the fence. If required post depths cannot be obtained, the posts shall be adequately secured by bracing or guying to prevent overturning of the fence due to sediment loading.
- 10. Use wood, steel or equivalent posts. The spacing of the support posts shall be a maximum of 6-feet. Posts shall consist of either:
  - Wood with minimum dimensions of 2 inches by 2 inches by 3 feet. Wood shall be free of defects such as knots, splits, or gouges.
  - No. 6 steel rebar or larger.
  - ASTM A 120 steel pipe with a minimum diameter of 1-inch.
  - U, T, L, or C shape steel posts with a minimum weight of 1.35 lbs./ft.
  - Other steel posts having equivalent strength and bending resistance to the post sizes listed above.
- 11. Locate silt fences on contour as much as possible, except at the ends of the fence,

2019 Stormwater Management Manual for Western Washington Volume II - Chapter 3 - Page 373

# **BMP C233: Silt Fence**

### Purpose

Silt fence reduces the transport of coarse sediment from a construction site by providing a temporary physical barrier to sediment and reducing the runoff velocities of overland flow.

Conditions of Use

- Silt fence may be used downslope of all disturbed areas.
- Silt fence shall prevent sediment carried by runoff from going beneath, through, or over the top of the silt fence, but shall allow the water to pass through the fence.
- Silt fence is not intended to treat concentrated flows, nor is it intended to treat substantial amounts of overland flow. Convey any concentrated flows through the drainage system to a sediment trapping BMP.
- Do not construct silt fences in streams or use in V-shaped ditches. Silt fences do not provide an adequate method of silt control for anything deeper than sheet or overland flow.

2019 Stormwater Management Manual for Western Washington Volume II - Chapter 3 - Page 370

where the fence shall be turned uphill such that the silt fence captures the runoff water and prevents water from flowing around the end of the fence.

- 12. If the fence must cross contours, with the exception of the ends of the fence, place check dams perpendicular to the back of the fence to minimize concentrated flow and erosion. The slope of the fence line where contours must be crossed shall not be steeper than 3H:1V.
  - Check dams shall be approximately 1-foot deep at the back of the fence. Check dams shall be continued perpendicular to the fence at the same elevation until
  - the top of the check dam intercepts the ground surface behind the fence. Check dams shall consist of crushed surfacing base course, gravel backfill for
  - walls, or shoulder ballast. Check dams shall be located every 10 feet along the fence where the fence must cross contours.

 Refer to Figure II-3.23: Silt Fence Installation by Slicing Method for slicing method details. The following are specifications for silt fence installation using the slicing method:

- 1. The base of both end posts must be at least 2- to 4-inches above the top of the geotextile fabric on the middle posts for ditch checks to drain properly. Use a hand level or string level, if necessary, to mark base points before installation.
- 2. Install posts 3- to 4-feet apart in critical retention areas and 6- to 7-feet apart in standard applications.
- 3. Install posts 24-inches deep on the downstream side of the silt fence, and as close as possible to the geotextile fabric, enabling posts to support the geotextile fabric from upstream water pressure.
- 4. Install posts with the nipples facing away from the geotextile fabric.
- 5. Attach the geotextile fabric to each post with three ties, all spaced within the top 8inches of the fabric. Attach each tie diagonally 45 degrees through the fabric, with each puncture at least 1-inch vertically apart. Each tie should be positioned to hang on a post nipple when tightening to prevent sagging.
- 6. Wrap approximately 6-inches of the geotextile fabric around the end posts and secure with 3 ties.
- 7. No more than 24-inches of a 36-inch geotextile fabric is allowed above ground level.
- 8. Compact the soil immediately next to the geotextile fabric with the front wheel of the tractor, skid steer, or roller exerting at least 60 pounds per square inch. Compact the upstream side first and then each side twice for a total of four trips. Check and correct the silt fence installation for any deviation before compaction. Use a flat-bladed shovel to tuck the fabric deeper into the ground if necessary.

2019 Stormwater Management Manual for Western Washington Volume II - Chapter 3 - Page 374

5 G IOB NO. 24014 DATE 3/24 SCALE 1"=20' DESIGNED J.W.T. DRAWN J.W.T. CHECKED R.S.F. APPROVED R.S.F. 3/7/2024 SHEET 11 OF 14

đ

U

S

Ш

S

1YAH 7466

7


J

**U**.

### Ponding height max. 24" POST SPACING " max. on open runs Attach fabric to 4' max. on pooling areas - Top of Fabric upstream side of post Belt FLOW ------POST DEPTH As much below ground Drive over each side of as fabric above ground silt fence 2 to 4 times with device exerting 60 p.s.i. or greate Diagonal attachmen 100% compaction 100% compaction oubles strengt ttachment Details: Gather fabric at posts, if needed. Utilize three ties per post, all within top 8 Position each tie diagonally, puncturing holes vertically a minimum of 1" apart. Hang each tie on a post nipple and tighten securely. Use cable ties (50 lbs) or soft No more than 24" of a 36" fabric is allowed above ground Slicing blade Horizontal chisel point (76 mm width) (18 mm width) Completed Installation Vibratory plow is not acceptable because of horizontal compaction NOT TO SCALE Silt Fence Installation by Slicing Method Revised June 2016 EPARTMENT ECOLOGY Please see http://www.ecy.wa.gov/copyright.html for copyright notice including permissions, State of Washington limitation of liability, and disclaimer.

Figure II-3.23: Silt Fence Installation by Slicing Method

2019 Stormwater Management Manual for Western Washington Volume II - Chapter 3 - Page 375



2019 Stormwater Management Manual for Western Washington Volume II - Chapter 3 - Page 273

# Maintenance Standards

- Repair any damage immediately.
- ping BMP.
- fence and remove the trapped sediment.
- the silt fence, or install a second silt fence.

# **BMP C234: Vegetated Strip**

# Purpose

## Conditions of Use

Average Contributing Area Slope	Average Contributing Area Per- cent Slope	Max Contributing area Flowpath Length
1.5H : 1V or flatter	67% or flatter	100 feet
2H : 1V or flatter	50% or flatter	115 feet
4H: 1V or flatter	25% or flatter	150 feet
6H: 1V or flatter	16.7% or flatter	200 feet
10H : 1V or flatter	10% or flatter	250 feet

· Vegetative buffer zones for streams, lakes or other waterways shall be established by the local permitting authority or other state or federal permits or approvals.

Design and Installation Specifications

High-visibility plastic fence shall be composed of a high-density polyethylene material and shall be at least four feet in height. Posts for the fencing shall be steel or wood and placed every 6 feet on center (maximum) or as needed to ensure rigidity. The fencing shall be fastened to the post every six inches with a polyethylene tie. On long continuous lengths of fencing, a tension wire or rope shall be used as a top stringer to prevent sagging between posts. The fence color shall be high-visibility orange. The fence tensile strength shall be 360 lbs/ft using the ASTM D4595 testing method.

If appropriate install fabric silt fence in accordance with BMP C233: Silt Fence to act as high-visibility fence. Silt fence shall be at least 3 feet high and must be highly visible to meet the requirements of

Metal fences shall be at least 3 feet high and must be highly visible.

Intercept and convey all evident concentrated flows uphill of the silt fence to a sediment trap-

# Check the uphill side of the silt fence for signs of the fence clogging and acting as a barrier to flow and then causing channelization of flows parallel to the fence. If this occurs, replace the

• Remove sediment deposits when the deposit reaches approximately one-third the height of

Replace geotextile fabric that has deteriorated due to ultraviolet breakdown.

Vegetated strips reduce the transport of coarse sediment from a construction site by providing a physical barrier to sediment and reducing the runoff velocities of overland flow.

# Vegetated strips may be used downslope of all disturbed areas

 Vegetated strips are not intended to treat concentrated flows, nor are they intended to treat substantial amounts of overland flow. Any concentrated flows must be conveyed through the drainage system to BMP C241: Sediment Pond (Temporary) or other sediment trapping BMP. The only circumstance in which overland flow can be treated solely by a vegetated strip, rather than by a sediment trapping BMP, is when the following criteria are met (see Table II-3.12: Contributing Drainage Area for Vegetated Strips):

# Table II-3.12: Contributing Drainage Area for Vegetated Strips

2019 Stormwater Management Manual for Western Washington

Volume II - Chapter 3 - Page 376

Inspect the area frequently to make sure flagging remains in place and the area remains undisturbed. Replace all damaged flagging immediately. Remove all materials located in the buffer area

Prevent disturbance of sensitive areas, their buffers, and other areas required to be left undis-

Protect areas where marking with survey tape may not provide adequate protection.

To establish clearing limits plastic, fabric, or metal fence may be used:

• At the boundary of sensitive areas, their buffers, and other areas required to be left uncleared. As necessary to control vehicle access to and on the site.

Metal fences shall be designed and installed according to the manufacturer's specifications.

# 2019 Stormwater Management Manual for Western Washington

Volume II - Chapter 3 - Page 274

# **BMP C101: Preserving Natural Vegetation**

Purpose

The purpose of preserving natural vegetation is to reduce erosion wherever practicable. Limiting site disturbance is the single most effective method for reducing erosion. For example, conifers can hold up to about 50 percent of all rain that falls during a storm. Up to 20-30 percent of this rain may never reach the ground but is taken up by the tree or evaporates. Another benefit is that the rain held in the tree can be released slowly to the ground after the storm.

### Conditions of Use

Natural vegetation should be preserved on steep slopes, near perennial and intermittent watercourses or swales, and on building sites in wooded areas.

- As required by local governments.
- Phase construction to preserve natural vegetation on the project site for as long as possible during the construction period.

## **Design and Installation Specifications**

Natural vegetation can be preserved in natural clumps or as individual trees, shrubs and vines.

The preservation of individual plants is more difficult because heavy equipment is generally used to remove unwanted vegetation. The points to remember when attempting to save individual plants are:

- Is the plant worth saving? Consider the location, species, size, age, vigor, and the work involved. Local governments may also have ordinances to save natural vegetation and trees.
- Fence or clearly mark areas around trees that are to be saved. It is preferable to keep ground disturbance away from the trees at least as far out as the dripline.

Plants need protection from three kinds of injuries:

- Construction Equipment This injury can be above or below the ground level. Damage results from scarring, cutting of roots, and compaction of the soil. Placing a fenced buffer zone around plants to be saved prior to construction can prevent construction equipment injuries.
- Grade Changes Changing the natural ground level will alter grades, which affects the plant's ability to obtain the necessary air, water, and minerals. Minor fills usually do not cause problems although sensitivity between species does vary and should be checked. Trees can typically tolerate fill of 6 inches or less. For shrubs and other plants, the fill should be less.

When there are major changes in grade, it may become necessary to supply air to the roots of plants. This can be done by placing a layer of gravel and a tile system over the roots before the fill is made. The tile system should be laid out on the original grade leading from a dry well

> 2019 Stormwater Management Manual for Western Washington Volume II - Chapter 3 - Page 271

# Maintenance Standards

If the fence has been damaged or visibility reduced, it shall be repaired or replaced immediately and visibility restored.

# **BMP C105: Stabilized Construction Access**

## Purpose

Stabilized construction accesses are established to reduce the amount of sediment transported onto paved roads outside the project site by vehicles or equipment. This is done by constructing a stabilized pad of quarry spalls at entrances and exits for project sites.

## Conditions of Use

Construction accesses shall be stabilized wherever traffic will be entering or leaving a construction site if paved roads or other paved areas are within 1,000 feet of the site.

For residential subdivision construction sites, provide a stabilized construction access for each residence, rather than only at the main subdivision entrance. Stabilized surfaces shall be of sufficient length/width to provide vehicle access/parking, based on lot size and configuration.

On large commercial, highway, and road projects, the designer should include enough extra materials in the contract to allow for additional stabilized accesses not shown in the initial Construction SWPPP. It is difficult to determine exactly where access to these projects will take place; additional materials will enable the contractor to install them where needed.

## Design and Installation Specifications

See Figure II-3.1: Stabilized Construction Access for details. Note: the 100' minimum length of the access shall be reduced to the maximum practicable size when the size or configuration of the site does not allow the full length (100').

Construct stabilized construction accesses with a 12-inch thick pad of 4-inch to 8-inch quarry spalls, a 4-inch course of asphalt treated base (ATB), or use existing pavement. Do not use crushed concrete, cement, or calcium chloride for construction access stabilization because these products raise pH levels in stormwater and concrete discharge to waters of the State is prohibited.

A separation geotextile shall be placed under the spalls to prevent fine sediment from pumping up into the rock pad. The geotextile shall meet the standards listed in Table II-3.2: Stabilized Construction Access Geotextile Standards.

**Table II-3.2: Stabilized Construction Access** 

Geotextile Standards **Geotextile Property Required Value** 

Grab Tensile Strength (ASTM D4751) 200 psi min.

2019 Stormwater Management Manual for Western Washington Volume II - Chapter 3 - Page 275

around the tree trunk. The system should then be covered with small stones to allow air to circulate over the root area.

Lowering the natural ground level can seriously damage trees and shrubs. The highest percentage of the plant roots are in the upper 12 inches of the soil and cuts of only 2-3 inches can cause serious injury. To protect the roots it may be necessary to terrace the immediate area around the plants to be saved. If roots are exposed, construction of retaining walls may be needed to keep the soil in place. Plants can also be preserved by leaving them on an undisturbed, gently sloping mound. To increase the chances for survival, it is best to limit grade changes and other soil disturbances to areas outside the dripline of the plant.

• Excavations - Protect trees and other plants when excavating for drainfields, power, water, and sewer lines. Where possible, the trenches should be routed around trees and large shrubs. When this is not possible, it is best to tunnel under them. This can be done with hand tools or with power augers. If it is not possible to route the trench around plants to be saved. then the following should be observed:

- · Cut as few roots as possible. When you have to cut, cut clean. Paint cut root ends with a wood dressing like asphalt base paint if roots will be exposed for more than 24-hours.
- Backfill the trench as soon as possible.

• Tunnel beneath root systems as close to the center of the main trunk to preserve most of the important feeder roots.

Some problems that can be encountered with a few specific trees are:

- Maple, Dogwood, Red alder, Western hemlock, Western red cedar, and Douglas fir do not readily adjust to changes in environment and special care should be taken to protect these
- The windthrow hazard of Pacific silver fir and madrona is high, while that of Western hemlock is moderate. The danger of windthrow increases where dense stands have been thinned. Other species (unless they are on shallow, wet soils less than 20 inches deep) have a low windthrow hazard.
- Cottonwoods, maples, and willows have water-seeking roots. These can cause trouble in sewer lines and infiltration fields. On the other hand, they thrive in high moisture conditions that other trees would not.
- Thinning operations in pure or mixed stands of Grand fir, Pacific silver fir, Noble fir, Sitka spruce, Western red cedar, Western hemlock, Pacific dogwood, and Red alder can cause serious disease problems. Disease can become established through damaged limbs, trunks, roots, and freshly cut stumps. Diseased and weakened trees are also susceptible to insect attack.

## Maintenance Standards

Inspect flagged and/or fenced areas regularly to make sure flagging or fencing has not been removed or damaged. If the flagging or fencing has been damaged or visibility reduced, it shall be repaired or replaced immediately and visibility restored.

> 2019 Stormwater Management Manual for Western Washington Volume II - Chapter 3 - Page 272

- PAM designated for these uses should be "water soluble" or "linear" or "non-crosslinked". Cross-linked or water absorbent PAM, polymerized in highly acidic (pH<2) conditions, are used to maintain soil moisture content.
- The PAM anionic charge density may vary from 2-30 percent; a value of 18 percent is typical. Studies conducted by the United States Department of Agriculture (USDA)/ARS demonstrated that soil stabilization was optimized by using very high molecular weight (12-15 mg/mole), highly anionic (>20% hydrolysis) PAM.
- PAM tackifiers are available and being used in place of guar and alpha plantago. Typically, PAM tackifiers should be used at a mixing rate of no more than 0.5-1 lb. per 1000 gallons of water in a hydromulch machine. Some tackifier product instructions say to use at an application rate of 3 – 5 lbs per acre, which can be too much. In addition, pump problems can occur at higher application rates due to increased viscosity.

Maintenance Standards

- PAM may be reapplied on actively worked areas after a 48-hour period.
- Reapplication is not required unless PAM treated soil is disturbed or unless turbidity levels show the need for an additional application. If PAM treated soil is left undisturbed, a reapplication may be necessary after two months. More PAM applications may be required for steep slopes, silty and clayey soils (USDA Classification Type "C" and "D" soils), long grades, and high precipitation areas. When PAM is applied first to bare soil and then covered with straw, a reapplication may not be necessary for several months.
- Loss of sediment and PAM may be a basis for penalties per RCW 90.48.080.
- PAM may affect the treatment efficiency of chitosan flocculent systems.

**BMP C130: Surface Roughening** 

# Purpose

Surface roughening aids in the establishment of vegetative cover, reduces runoff velocity, increases infiltration, and provides for sediment trapping through the provision of a rough soil surface. Horizontal depressions are created by operating a tiller or other suitable equipment on the contour or by leaving slopes in a roughened condition by not fine grading them.

Use this BMP in conjunction with other BMPs such as BMP C120: Temporary and Permanent Seeding, BMP C121: Mulching, or BMP C124: Sodding.

# **Conditions for Use**

- All slopes steeper than 3H:1V and greater than 5 vertical feet require surface roughening to a depth of 2 to 4 inches prior to seeding.
- Areas that will not be stabilized immediately may be roughened to reduce runoff velocity until seeding takes place.

2019 Stormwater Management Manual for Western Washington Volume II - Chapter 3 - Page 307

đ 0 S Ш 7 U IOB NO. 24014 **DATE 3/24** SCALE 1"=20' DESIGNED J.W.T. DRAWN J.W.T.

3/7/2024

CHECKED R.S.F. APPROVED R.S.F.



Slopes with a stable rock face do not require roughening.

• Slopes where mowing is planned should not be excessively roughened.


Design and Installation Specifications

There are different methods for achieving a roughened soil surface on a slope, and the selection of an appropriate method depends upon the type of slope. Roughening methods include stair-step grading, grooving, contour furrows, and tracking. See Figure II-3.5: Surface Roughening by Tracking and Contour Furrows. Factors to be considered in choosing a roughening method are slope steepness, mowing requirements, and whether the slope is formed by cutting or filling.


- Disturbed areas that will not require mowing may be stair-step graded, grooved, or left rough after filling.
- Stair-step grading is particularly appropriate in soils containing large amounts of soft rock. Each "step" catches material that sloughs from above, and provides a level site where vegetation can become established. Stairs should be wide enough to work with standard earth moving equipment. Stair steps must be on contour or gullies will form on the slope.
- Areas that will be mowed (these areas should have slopes less steep than 3H:1V) may have small furrows left by disking, harrowing, raking, or seed-planting machinery operated on the contour.
- Graded areas with slopes steeper than 3H:1V but less than 2H:1V should be roughened before seeding. This can be accomplished in a variety of ways, including "track walking," or driving a crawler tractor up and down the slope, leaving a pattern of cleat imprints parallel to slope contours.
- Tracking is done by operating equipment up and down the slope to leave horizontal depressions in the soil.
- Maintenance Standards
- Areas that are surface roughened should be seeded as quickly as possible.
- . Regular inspections should be made of the area. If rills appear, they should be re-roughened and re-seeded immediately.

2019 Stormwater Management Manual for Western Washington

Volume II - Chapter 3 - Page 308



2019 Stormwater Management Manual for Western Washington Volume II - Chapter 3 - Page 312





2019 Stormwater Management Manual for Western Washington Volume II - Chapter 3 - Page 309

compliance with this BMP. Use vacuum street sweepers. • Remove mud and other dirt promptly so it does not dry and then turn into dust.

- Techniques that can be used for unpaved roads and lots include:
  - unpaved roads and lots.
- that make up the surface and base materials.

- struction.
- treatments.

- Pave unpaved permanent roads and other trafficked areas.

Maintenance Standards

# Purpose

Keep quantities of erosion prevention and sediment control materials on the project site at all times to be used for regular maintenance and emergency situations such as unexpected heavy rains. Having these materials on-site reduces the time needed to replace existing or implement new BMPs when inspections indicate that existing BMPs are not meeting the Construction SWPPP requirements. In addition, contractors can save money by buying some materials in bulk and storing them at their office or yard.

## Conditions of Use

2019 Stormwater Management Manual for Western Washington

# RAMAIYAH AND SUBRAMANIAN RESIDENCE NW 1/4, SE 1/4, SECTION 30, TOWNSHIP 24 NORTH, RANGE 5 EAST, W.M. MERCER ISLAND, WASHINGTON



Revised June 2016 Please see http://www.ecy.wa.gov/copyright.html for copyright notice including permissions, limitation of liability, and disclaime

- Lower speed limits. High vehicle speed increases the amount of dust stirred up from
- Upgrade the road surface strength by improving particle size, shape, and mineral types
- Add surface gravel to reduce the source of dust emission. Limit the amount of fine particles (those smaller than .075 mm) to 10 to 20 percent.
- Use geotextile fabrics to increase the strength of new roads or roads undergoing recon-
- Encourage the use of alternate, paved routes, if available,
- Apply chemical dust suppressants using the admix method, blending the product with the top few inches of surface material. Suppressants may also be applied as surface
- Limit dust-causing work on windy days.
- Respray area as necessary to keep dust to a minimum.
- **BMP C150: Materials on Hand**

 Construction projects of any size or type can benefit from having materials on hand. A small commercial development project could have a roll of plastic and some gravel available for immediate protection of bare soil and temporary berm construction. A large earthwork project, such as highway construction, might have several tons of straw, several rolls of plastic, flexible

Volume II - Chapter 3 - Page 314

# **BMP C131: Gradient Terraces**

## Purpose

Gradient terraces reduce erosion damage by intercepting surface runoff and conveying it to a stable outlet at a non-erosive velocity.

## Conditions of Use

Gradient terraces are normally limited to bare land having a water erosion problem. They should not be constructed on deep sands or on soils that are too stony, steep, or shallow to permit practical and economical installation and maintenance. Gradient terraces may only be used where suitable outlets are or will be made available.

### Design and Installation Specifications

 The maximum vertical spacing of gradient terraces should be determined by the following method:

VI = (0.8)s + y

Where:

- VI = vertical interval in feet
- s = land rise per 100 feet, expressed in feet
- y = a soil and cover variable with values from 1.0 to 4.0

Values of "y" are influenced by soil erodibility and cover practices. The lower values are applicable to erosive soils where little to no residue is left on the surface. The higher value is applicable only to erosion-resistant soils where a large amount of residue (11/2 tons of straw/acre equivalent) is on the surface.

- The minimum constructed cross-section should meet the design dimensions.
- The top of the constructed ridge should not be lower at any point than the design elevation plus the specified overfill for settlement. The opening at the outlet end of the terrace should have a cross section equal to that specified for the terrace channel.
- Channel grades may be either uniform or variable with a maximum grade of 0.6 feet per 100 feet length (0.6%). For short distances, terrace grades may be increased to improve alignment. The channel velocity should not exceed that which is nonerosive for the soil type.
- All gradient terraces should have adequate outlets. Such an outlet may be a grassed waterway, vegetated area, or tile outlet. In all cases the outlet must convey runoff from the terrace or terrace system to a point where the outflow will not cause damage. Vegetative cover and energy dissipators should be used in the outlet channel.
- The design elevation of the water surface of the terrace should not be lower than the design elevation of the water surface in the outlet at their junction, when both are operating at design

2019 Stormwater Management Manual for Western Washington Volume II - Chapter 3 - Page 310

pipe, sandbags, geotextile fabric and steel "T" posts.

- Materials should be stockpiled and readily available before any site clearing, grubbing, or earthwork begins. A large contractor or project proponent could keep a stockpile of materials that are available for use on several projects.
- If storage space at the project site is at a premium, the contractor could maintain the materials at their office or yard. The office or yard must be less than an hour from the project site.

# Design and Installation Specifications

Depending on project type, size, complexity, and length, materials and quantities will vary. A good minimum list of items that will cover numerous situations includes:

- Clear Plastic, 6 mil
- Drainpipe, 6 or 8 inch diameter
- Sandbags, filled
- Straw Bales for mulching
- Quarry Spalls
- Washed Gravel
- Geotextile Fabric
- Catch Basin Inserts
- Steel "T" Posts
- Silt fence material
- Straw Wattles
- Maintenance Standards
- All materials with the exception of the quarry spalls, steel "T" posts, and gravel should be kept covered and out of both sun and rain.
- Re-stock materials as needed.

## **BMP C151: Concrete Handling**

## Purpose

Concrete work can generate process water and slurry that contain fine particles and high pH, both of which can violate water quality standards in the receiving water. Concrete spillage or concrete discharge to waters of the State is prohibited. Use this BMP to minimize and eliminate concrete, concrete process water, and concrete slurry from entering waters of the State.

> 2019 Stormwater Management Manual for Western Washington Volume II - Chapter 3 - Page 315

		BY DATE BY DATE	
<ul> <li>flow.</li> <li>Vertical spacing determined by the above methods may be increased as much as 0.5 feet or 10 percent, whichever is greater, to provide better alignment or location, to avoid obstacles, to adjust for equipment size, or to reach a satisfactory outlet. The drainage area above the terrace should not exceed the area that would be drained by a terrace with normal spacing.</li> <li>The terrace should have enough capacity to handle the peak runoff expected from a 2-year, 24-hour design storm without overtopping.</li> <li>The terrace cross-section should be proportioned to fit the land slope.</li> <li>The ridge height should include a reasonable settlement factor.</li> <li>The ridge should have a minimum top width of 3 feet at the design height.</li> </ul>		REVISIONS	
<ul> <li>The minimum cross-sectional area of the terrace channel should be 8 square feet for land slopes of 5 percent or less, 7 square feet for slopes from 5 to 8 percent, and 6 square feet for slopes steeper than 8 percent. The terrace can be constructed wide enough to be maintained using a small vehicle.</li> <li>Maintenance Standards</li> <li>Maintenance should be performed as needed. Terraces should be inspected regularly; at least once per year, and after large storm events.</li> </ul>		TESC DETAILS	
2019 Stormwater Management Manual for Western Washington Volume II - Chapter 3 - Page 311	RAMANAN SUBRAMANAN	MERCER ISLAND, WA 98040 MERCER ISLAND, WA 98040 MERETT TOWNHOMES Y OF EVERETT SUBDIVISION FOR ILLAR CAPITAL INVESTMENTS LLC	
<ul> <li>Design and Installation Specifications</li> <li>The vegetated strip shall consist of a continuous strip of dense vegetation with topsoil for a minimum of a 25-foot length along the flowpath. Grass-covered, landscaped areas are generally not adequate because the volume of sediment overwhelms the grass. Ideally, vegetated strips shall consist of undisturbed native growth with a well-developed soil that allows for infiltration of runoff.</li> </ul>		VC. EV	
<ul> <li>of runoff.</li> <li>The slope within the vegetated strip shall not exceed 4H:1V.</li> <li>The uphill boundary of the vegetated strip shall be delineated with clearing limits.</li> <li><i>Maintenance Standards</i></li> <li>Any areas damaged by erosion or construction activity shall be seeded immediately and protected by mulch.</li> <li>If more than 5 feet of the original vegetated strip width has had vegetation removed or is being eroded, sod must be installed.</li> <li>If there are indications that concentrated flows are traveling across the vegetated strip, stormwater runoff controls must be installed to reduce the flows entering the vegetated strip, or additional perimeter protection must be installed.</li> </ul>		- SURVEYORS SULTANTS, IN	
BMP C235: Wattles <i>Purpose</i> Wattles are temporary erosion and sediment control barriers consisting of straw, compost, or other material that is wrapped in netting made of natural plant fiber or similar encasing material. They reduce the velocity and can spread the flow of rill and sheet runoff, and can capture and retain sed- iment. <b>Conditions of Use</b> • Wattles shall consist of cylinders of plant material such as weed-free straw, coir, wood chips, excelsior, or wood fiber or shavings encased within netting made of natural plant fibers unaltered by synthetic materials. • Use wattles:		ENGINEERS ENGINEERS ASTSIDE CON. 20 N.W. MALL ST., SUITE B SAQUAH, WASHINGTON 98027 1:(425)392-5351 FAX:392-4676	
<ul> <li>In disturbed areas that require immediate erosion protection.</li> <li>On exposed soils during the period of short construction delays, or over winter months.</li> <li>On slopes requiring stabilization until permanent vegetation can be established.</li> <li>The material used dictates the effectiveness period of the wattle. Generally, wattles are effective for one to two seasons.</li> </ul> 2019 Stormwater Management Manual for Western Washington Volume II - Chapter 3 - Page 377			
	P. OF WASHING P. OF WASHING P. SOF WASHING P. SOF WASHING C. S. FRED SOF WASHING C. S. FRED SOF WASHING C. S. FRED SOF WASHING C. S. FRED C. S. S. FRED C. S.	JOB NO. 24014 DATE 3/24 SCALE 1"=20' DESIGNED J.W.T. DRAWN J.W.T. CHECKED R.S.F. APPROVED R.S.F.	

3/7/2024


SHEET 13 OF 14

 Prevent rilling beneath wattles by entrenching and overlapping wattles to prevent water from passing between them.

Design Criteria

- See Figure II-3.24: Wattles for typical construction details.
- Wattles are typically 8 to 10 inches in diameter and 25 to 30 feet in length.
- Install wattles perpendicular to the flow direction and parallel to the slope contour.
- Place wattles in shallow trenches, staked along the contour of disturbed or newly constructed slopes. Dig narrow trenches across the slope (on contour) to a depth of 3- to 5-inches on clay soils and soils with gradual slopes. On loose soils, steep slopes, and areas with high rainfall, the trenches should be dug to a depth of 5- to 7- inches, or 1/2 to 2/3 of the thickness of the wattle.
- Start building trenches and installing wattles from the base of the slope and work up. Spread excavated material evenly along the uphill slope and compact it using hand tamping or other methods.
- Construct trenches at intervals of 10- to 25-feet depending on the steepness of the slope, soil type, and rainfall. The steeper the slope the closer together the trenches. • Install the wattles snugly into the trenches and overlap the ends of adjacent wattles 12 inches
- behind one another. • Install stakes at each end of the wattle, and at 4-foot centers along entire length of wattle.
- If required, install pilot holes for the stakes using a straight bar to drive holes through the wattle and into the soil.
- Wooden stakes should be approximately 0.75 x 0.75 x 24 inches min. Willow cuttings or 3/8inch rebar can also be used for stakes.
- Stakes should be driven through the middle of the wattle, leaving 2 to 3 inches of the stake protruding above the wattle.

2019 Stormwater Management Manual for Western Washington Volume II - Chapter 3 - Page 378



2019 Stormwater Management Manual for Western Washington Volume II - Chapter 3 - Page 379

# Maintenance Standards

· Wattles may require maintenance to ensure they are in contact with so entrenched, especially after significant rainfall on steep sandy soils.

 Inspect the slope after significant storms and repair any areas where w abutted or water has scoured beneath the wattles.

# Approved as Functionally Equivalent

Ecology has approved products as able to meet the requirements of this BMP pass through the Technology Assessment Protocol - Ecology (TAPE) proces may choose not to accept these products, or may require additional testing pri local use. Products that Ecology has approved as functionally equivalent are a Ecology's website at:

### https://ecology.wa.gov/Regulations-Permits/Guidance-technical-assistance/ mittee-guidance-resources/Emerging-stormwater-treatment-technologies

**BMP C236: Vegetative Filtration** 

# Purpose

Vegetative filtration as a BMP is used in conjunction with detention storage in the tanks or BMP C241: Sediment Pond (Temporary), BMP C206: Level Spread tem with surface intake. Vegetative filtration improves turbidity levels of storm tering runoff through existing vegetation where undisturbed forest floor duff lay with thatch layer are present. Vegetative filtration can also be used to infiltrate from foundations, vaults, and trenches as long as runoff does not occur.

# Conditions of Use

- For every five acres of disturbed soil use one acre of grass field, farm pa area. Reduce or increase this area depending on project size, ground v other site conditions.
- Wetlands shall not be used for vegetative filtration.
- Do not use this BMP in areas with a high ground water table, or in areas seasonal ground water table during the use of this BMP.
- . This BMP may be less effective on soils that prevent the infiltration of th
- Using other effective source control measures throughout a construction generation of additional highly turbid water and may reduce the time per this BMP.
- Stop distributing water into the vegetated filtration area if standing wate

2019 Stormwater Management Manual for Western Washir Volume II - Chapter 3 - Page 380

	<b>DATE</b> SHALL TS, INC.
	EVISIONS BY DATE BY DATE DATE DATE BY DATE
	HIS SHEET ASTSIDE CC
	ORTH ON T
	NS SET F
	REVISIONS © THE PLANS
d thoroughly	
es are not tightly	LAILS
he products did not Local jurisdictions to consideration for	ETA
lable for review on <u>rmwater-per-</u>	
	TESC
e form of portable	
and a pumping sys- iter discharges by fil- r or established lawn ewatering waste	
	MOWES 1848N FOR TMENTS LLC
ure, or wooded er table height, and	MCON SISSA8N MENTS
at will have a high	P BR V
rater, such as hard ite will prevent the	AL IN USE
d or area need for r erosion results.	
ton	
	NC.
	RS S, I
	ENGINEERS - SURVEYORS ENGINEERS - SURVEYORS EASTSIDE CONSULTANTS, INC. 1320 NW. MALL ST., SUITE B 1320
	S - S
	<b>DE</b> SUITE E AX:392-4
	EN MALL ST. MALL ST. MALL ST.
	<b>AS</b> s20 N.W. 1:(425)39
	17 S T
S. FREDENIN	
CIF WASKING	JOB NO. 24014 Date 3/24 Scale 1"=20'
2 6 A 39053 EO 2 CONTENENT CONTENT CONTENENT CONTENT CONTENT CONTENT CONTENT CONTENT CONTENT CONTENT CONTENT CONTENT CONTENT CONTENT CONTENT CONTENT CONTENT CONTENT CONTENT CONTENT CONTENT CONTENT	DESIGNED J.W.T. DRAWN J.W.T. CHECKED R.S.F. APPROVED R.S.F.